
## TRUNK COVERING REMOVAL/INSTALLATION

id091700462500

## 1. Remove fasteners.



- Remove the trunk covering.
  Install in the reverse order of removal.

ac5wzw00001410