AIR BAG SYSTEM WARNING ALARM

id081000500400

Purpose

• The air bag system warning alarm notifies the driver that a malfunction occurred in the air bag system warning light.

Function


• When a malfunction occurs in the air bag system warning light, the air bag system alarm sounds.

Construction

• The air bag system warning alarm sounds a buzzer in the instrument cluster.

Operation

- The SAS control module sends the air bag system warning alarm trigger signal to the instrument cluster via CAN communication to sound the buzzer in the instrument cluster.
- If all of the following conditions are met, the SAS control module sends the air bag system warning alarm trigger signal to the instrument cluster.
 - SAS control module detects DTC B00D2:01 (air bag system warning light malfunction)
 - SAS control module detects DTCs other than DTC B00D2:01



· Refer to the air bag system warning alarm for the air bag system warning alarm sound interval.

ac5wzn00000802

Fail-safe

· Function not equipped.