AERODYNAMIC id091600010400


Purpose/Function

• For improved aerodynamics, under covers are installed to the under-surface of the vehicle.

Construction

- The vehicle is equipped with the following four (4) under covers.
 Front under cover No.1

 - Front under cover No.2
 - Floor under cover
 - Seal plate



ac5wzn00001278

Fail-safe

• Function not equipped.