BAROMETRIC PRESSURE (BARO) SENSOR INSPECTION [SKYACTIV-G 2.0]

id0140f4801100

Voltage Inspection

Note

- · Because the BARO sensor is integrated in the PCM, replacing the BARO sensor includes replacement of
- 1. Connect the M-MDS to the DLC-2.
- 2. Switch the ignition ON (engine off or on).
- 3. Verify that the BARO sensor output voltage (PID: BARO) is within the specification. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) (See PCM INSPECTION [SKYACTIV-G 2.0].)

 • If not as specified, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)

Specification

