DTC P0600:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0102h4850400

DTC P0600:00	Serial communication link	
DETECTION CONDITION	 PCM internal malfunction. Diagnostic support note This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory. 	
FAIL-SAFE FUNCTION	Not applicable	
POSSIBLE CAUSE	PCM malfunction	
SYSTEM WIRING DIAGRAM	Not applicable	

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/	Yes	Go to the next step.
	SNAPSHOT DATA HAS BEEN RECORDED	No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data
	Has the FREEZE FRAME DATA (Mode 2)/		on the repair order, then go to the next step.
	snapshot data been recorded?		
2	VERIFY RELATED SERVICE INFORMATION	Yes	Perform repair or diagnosis according to the available
	AVAILABILITY		Service Information.
	Verify related Service Information availability.		If the vehicle is not repaired, go to the next step.
	Is any related Service Information available?	No	Go to the next step.
3	VERIFY DTC TROUBLESHOOTING	Yes	Replace the PCM, then go to the next step.
	COMPLETED		(See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0,
	Always reconnect all disconnected connectors.		SKYACTIV-G 2.5].)
	Clear the DTC from the PCM memory using the	No	Go to the next step.
	M-MDS.		
	(See AFTER REPAIR PROCEDURE		
	[SKYACTIV-G 2.0, SKYACTIV-G 2.5].)		
	Perform the KOEO or KOER self test.		
	(See KOEO/KOER SELF TEST [SKYACTIV-G		
	2.0, SKYACTIV-G 2.5].)		
	Is the same DTC present?		
4	VERIFY AFTER REPAIR PROCEDURE	Yes	Go to the applicable DTC inspection.
	Perform the "AFTER REPAIR PROCEDURE".		(See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
	(See AFTER REPAIR PROCEDURE	No	DTC troubleshooting completed.
	[SKYACTIV-G 2.0, SKYACTIV-G 2.5].)		
	Are any DTCs present?		