PARKING BRAKE LEVER INSPECTION

id041200800900

Stroke Inspection

- 1. Pump the brake pedal a few times.
- 2. Pull the parking brake lever two to three times.
- Inspect the parking brake stroke by slowly pulling at point A 50 mm {2.0 in} from the end of the parking brake lever with a force of 98 N {10 kgf, 22 lbf} and counting the number of notches (clicking sound).
 - · If not within the specification, adjust the parking brake lever.

Parking brake lever stroke when pulled at 98 N {10 kgf, 22 lbf} 2-3 notches

