DTC U3000:55

System malfunction location	Configuration error (SAS control module internal malfunction)
Detection condition	<ul> <li>Warning</li> <li>Detection conditions are for understanding the DTC outline before performing an inspection.         Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure.</li> <li>SAS control module falsely recognizes that the SAS control module has inflators with no settings due to a SAS control module internal malfunction</li> </ul>
Fail-safe	_
Possible cause	SAS control module malfunction
System wiring diagram	_

## **Diagnostic Procedure**

ACTION
Replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION.)