## AIR FUEL RATIO (A/F) SENSOR DATA RESET [SKYACTIV-D 2.2]

id0140z7780800

- 1. Connect the M-MDS to the DLC-2.
- 2. After the vehicle is identified, select the following item from the initial screen of the M-MDS.
  - (1) Select the "Powertrain".
- 3. Then, select the items from the screen menu in the following order.
  (1) Select the "Data Reset".
  (2) Select the "O2 sensor".
- 4. Perform the procedure according to the directions on the screen.