
EXTERIOR TRIM

Outline

• Exterior is equipped with the under cover on the vehicles under-surface.

Structure View



VEHICLES UNDER-SURFACE

