
## **COOLING SYSTEM LOCATION INDEX [SKYACTIV-D 2.2]**





1	Water pump
	(See WATER PUMP REMOVAL/INSTALLATION
	[SKYACTIV-D 2.2].)
2	Thermostat
	(See THERMOSTAT REMOVAL/INSTALLATION
	[SKYACTIV-D 2.2].)
	(See THERMOSTAT INSPECTION [SKYACTIV-D
	2.2].)
3	Coolant reserve tank
	(See ENGINE COOLANT LEVEL INSPECTION
	[SKYACTIV-D 2.2].)
	(See COOLANT RESERVE TANK REMOVAL/
	INSTALLATION [SKYACTIV-D 2.2].)
4	Cooling fan motor No.2
	(See COOLING FAN MOTOR REMOVAL/
	INSTALLATION [SKYACTIV-D 2.2].)
	(See COOLING FAN MOTOR INSPECTION
	[SKYACTIV-D 2.2].)

5 Fan control module No.2
(See FAN CONTROL MODULE INSPECTION
[SKYACTIV-D 2.2].)
6 Fan control module No.1
(See FAN CONTROL MODULE INSPECTION
[SKYACTIV-D 2.2].)
7 Cooling fan motor No.1
(See COOLING FAN MOTOR REMOVAL/
INSTALLATION [SKYACTIV-D 2.2].)
(See COOLING FAN MOTOR INSPECTION
[SKYACTIV-D 2.2].)

8 Radiator
(See ENGINE COOLANT PROTECTION
INSPECTION [SKYACTIV-D 2.2].)
(See ENGINE COOLANT REPLACEMENT
[SKYACTIV-D 2.2].)
(See ENGINE COOLANT LEAKAGE INSPECTION
[SKYACTIV-D 2.2].)
(See RADIATOR REMOVAL/INSTALLATION
[SKYACTIV-D 2.2].)

Cooling system cap
(See COOLING SYSTEM CAP INSPECTION
[SKYACTIV-D 2.2].)