ACCELERATOR PEDAL POSITION (APP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2] id0140z7877800

Note

- Because the APP sensor is integrated in the accelerator pedal, replacing the APP sensor includes replacement of the accelerator pedal.
- 1. Remove the accelerator pedal. (See ACCELERATOR PEDAL REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)