
# OIL PAN [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0111h5002300

# **Purpose, Function**

• The engine oil required for lubrication in the engine accumulates in the oil pan.

• The oil pan is installed on the lower part of the cylinder block. **SKYACTIV-G 2.0** 



## **SKYACTIV-G 2.5**

• Silicone sealant with excellent sealing has been adopted for the oil pan gasket.

