
## **SEAT BELT LOCATION INDEX**

id081100804200



1	Rear seat belt
	(See REAR SEAT BELT REMOVAL/
	INSTALLATION.)
	(See SEAT BELT INSPECTION.)
2	Rear center seat belt
	(See REAR CENTER SEAT BELT REMOVAL/
	INSTALLATION.)
	(See SEAT BELT INSPECTION.)
3	Adjuster anchor
	(See ADJUSTER ANCHOR REMOVAL/
	INSTALLATION.)
4	Front seat belt
	(See FRONT SEAT BELT REMOVAL/
	INSTALLATION.)
	(See SEAT BELT INSPECTION.)

5	Front buckle
	(See FRONT BUCKLE REMOVAL/
	INSTALLATION.)
	(See BUCKLE SWITCH INSPECTION.)
6	Rear buckle
	(See REAR BUCKLE REMOVAL/INSTALLATION.)
	(See BUCKLE SWITCH INSPECTION.)