INTAKE SHUTTER VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0116e1708200

Note

• If the intake shutter valve is replaced, perform the intake shutter valve initialization procedure.

Operation After Replacing Intake Shutter Valve

1. If the intake shutter valve is replaced, perform the following procedure.


STEP	ACTION	PAGE/CONDITION
1	Perform intake shutter valve initialization procedure.	(See INTAKE SHUTTER VALVE INITIALIZATION [SKYACTIV-D 2.2].)
2	Switch the ignition off.	——————————————————————————————————————
3	Wait for 20 s.	_
4	Switch the ignition ON (engine off).	_
5	Perform KOEO self-test procedure.	(See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].)
6	Start the engine.	-
7	Verify that the check engine light does not illuminate.	-
8	Perform KOER self-test procedure.	(See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].)
9	Switch the ignition off.	_

Intake Shutter Valve Removal/Installation

- 1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
- 2. Remove front under cover No.1 and front under cover No.2. (See FRONT UNDER COVER No.1 REMOVAL/INSTALLATION.) (See FRONT UNDER COVER No.2 REMOVAL/INSTALLATION.)
- 3. Remove the charge air cooler outlet hose. (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
- 4. Drain the engine coolant. (See ENGINE COOLANT REPLACEMENT [SKYACTIV-D 2.2].)
- 5. Remove in the order shown in the figure.

1	Intake shutter valve connector	
2	Water hose No.1	
	(See Water hose No.1 removal note.)	
	(See Water hose No.1 installation note.)	
3	Water hose No.2	
	(See Water hose No.2 installation note.)	
4	Intake shutter valve	
	(See Operation After Replacing Intake Shutter Valve.)	

6. Install in the reverse order of removal.




ac5wzw00005812

Water hose No.1 removal note


- 1. Remove the coolant reserve tank. (See COOLANT RESERVE TANK REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
- 2. Remove the starter terminal B cable installation nut.

- 3. Detach the wiring harness clips shown in the figure.4. Remove the water hose No.1



Water hose No.2 installation note


1. Install water hose No.2 as shown in the figure.



Water hose No.1 installation note


1. Install water hose No.1 as shown in the figure.

Intake shutter valve side



Thermostat side

ac5wzw00005815



ac5wzw00005831