LICENSE PLATE LIGHT id091800012100

## **Purpose**


• The license plate lights shine light on the license plate during nighttime driving.

#### **Function**

• The license plate lights illuminate in conjunction with the operation of the light switch.

## Construction

· The license plate lights are installed to the liftgate.




ac5uun00000572

# Operation

- When the light switch is operated to the TNS position, a TNS signal is input to the start stop unit.
  The start stop unit sends the TNS signal to the front body control module (FBCM).
  When the front body control module (FBCM) receives the TNS signal, it turns the TNS relay on.

- 4. When the TNS relay turns on, the license plate bulbs are illuminated.



Fail-safeFunction not equipped.