
EGR COOLER REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0116e1099000


Note

- If the EGR cooler bypass valve is replaced, perform the EGR initialization procedure.
- 1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
- Remove the engine cover. (See ENGINE COVER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
- 3. Remove the air cleaner. (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
- 4. Remove the battery and the battery tray. (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
- 5. Remove the following parts as a single unit: (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
 - · Air hose
 - · Air inlet pipe
 - Breather hose
 - Turbocharger air inlet hose
 - · Blow-by heater
- 6. Set the turbocharger air outlet pipe, turbocharger air outlet hose, and air intake pipe aside as a single unit as shown in the figure. (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
- 7. Drain the engine coolant. (See ENGINE COOLANT REPLACEMENT [SKYACTIV-D 2.2].)




ac5wzw00005724


8. Set the water pipe component aside as shown in the figure.



Detach the wiring harness clips shown in the figure.
 Remove the EGR pipe (EGR valve side). (See EGR PIPE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)



11. Remove in the order shown in the figure.



acmzzw00000116

1	Vacuum hose No.1
	(See Vacuum Hose No.1 Installation Note.)
2	Vacuum hose No.2
	(See Vacuum Hose No.2 Installation Note.)
3	Water hose
4	EGR cooler insulator
5	Vacuum hose No.3
	(See Vacuum Hose No.3 Removal Note.)
	(See Vacuum Hose No.3 Installation Note.)
6	Vacuum pipe
	(See Vacuum Pipe Installation Note.)
7	EGR cooler

12. Install in the reverse order of removal.


Vacuum Hose No.3 Removal Note

- Disconnect vacuum hose No.3 on the vacuum pipe bracket side.
 Disconnect vacuum hose No.3, the vacuum pipe and the EGR cooler as a single unit.
- 3. Remove vacuum hose No.3.

Vacuum Pipe Installation Note


Note

 When installing the vacuum pipe, verify the tightening torque for the bolt shown in the figure because the wiring harness bracket bolt may have loosened.




Vacuum Hose No.3 Installation Note


1. Install vacuum hose No.3 as shown in the figure. **Vacuum pipe side**



Vacuum pipe side (If equipped)




Vacuum pipe bracket side



Vacuum Hose No.2 Installation Note

1. Install vacuum hose No.2 as shown in the figure.



ac5wzw00005747

Vacuum Hose No.1 Installation Note

1. Install vacuum hose No.1 as shown in the figure.

