PUSH BUTTON START SYSTEM DOES NOT OPERATE [SECURITY AND LOCKS]

id0903k7012600

Description

• When the push button start is pressed, the ignition cannot be switched to ACC or ON (engine off).

Possible cause

- Open circuit in wiring harness between the following terminals:
 Start stop unit terminal 1H and push button start terminal C
 Start stop unit terminal 2J and push button start terminal I
 Start stop unit terminal 1AF and ground
 Start stop unit terminal 2B and ground

 - Start stop unit terminal 2A and ground

Diagnostic Procedure

Step	Inspection		Action
1	INSPECT IF MALFUNCTION CAUSE IS OPEN	Yes	Go to the next step.
	CIRCUIT IN WIRING HARNESS BETWEEN START	No	• Repair or replace the wiring harness for an open circuit.
	STOP UNIT AND PUSH BUTTON START		After repair procedure, go to Step 3.
	Disconnect the negative battery cable.		
	(See NEGATIVE BATTERY CABLE		
	DISCONNECTION/CONNECTION [SKYACTIV-G		
	2.0, SKYACTIV-G 2.5].)		
	(See NEGATIVE BATTERY CABLE		
	DISCONNECTION/CONNECTION [SKYACTIV-G		
	2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].)		
	(See NEGATIVE BATTERY CABLE		
	DISCONNECTION/CONNECTION [SKYACTIV-D		
	2.2].)		
	Disconnect the Start stop unit and push button start		
	connector.		
	• Inspect for continuity between the following		
	terminals (vehicle wiring harness). — Start stop unit terminal 1H and push button start		
	terminal C		
	Start stop unit terminal 2J and push button start		
	terminal I		
	• Is there continuity?		
2	INSPECT IF MALFUNCTION CAUSE IS OPEN	Yes	Go to the next step.
_	CIRCUIT IN WIRING HARNESS BETWEEN START	No	Repair or replace the wiring harness for an open circuit.
	STOP UNIT AND GROUND		After repair, go to the next step.
	Verify that the start stop unit connector is		, , , , , , , , , , , , , , , , , , , ,
	disconnected.		
	Inspect for continuity between the following		
	terminals (vehicle wiring harness).		
	 Start stop unit terminal 1AF and ground 		
	 Start stop unit terminal 2B and ground 		
	Start stop unit terminal 2A and ground		
	Is there continuity?		
3	VERIFY IF MALFUNCTION CAUSE WAS	Yes	Troubleshooting completed. (Explain the contents of the
	CORRECTED		servicing to the customer.)
	Does the push button start button operate correctly?	No	If the malfunction has not been resolved, repeat the
			inspection from Step 1.