BAROMETRIC PRESSURE (BARO) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

Note

- Because the BARO sensor is integrated in the PCM, replacing the BARO sensor includes replacement of the PCM.
- 1. Remove the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)