FRONT DOOR LOCK ACTUATOR

id091400108300

Purpose

Performs lock/unlock switching of the front doors electrically based on the signal from the rear body control
module (RBCM).

Function

Lock function


 The built-in motor is operated in the lock direction, and the latch lever will not release even if an inner/outer handle is operated.

Unlock function

 The built-in motor is operated in the unlock direction and the latch lever releases when an inner/outer handle is operated.

Construction

- The front door lock actuator has a built-in motor, and the link installed to the motor moves in the lock/unlock direction in conjunction with the motor rotation.
- The link for the inner/outer handle and latch lever can be disconnected by the movement of the link installed to the motor.
- When the door lock is unlocked, the link for the inner/outer handle and latch lever release is connected.
- · When the door lock is locked, the link for the inner/outer handle and latch lever release is disconnected.



ac5wzn00000888

Operation

Lock operation


- 1. The front door lock actuator rotates the built-in motor to the lock side.
- 2. When the motor rotates to the lock side, the link installed to the motor moves in the lock direction, and the link for the inner/outer handle and latch lever release disconnects.
- When the link connection is disconnected, the latch lever cannot be released even if an inner/outer handle is operated.

Unlock operation

- 1. The front door lock actuator rotates the built-in motor to the unlock side.
- 2. When the motor rotates to the unlock side, the link installed to the motor moves in the unlock direction, and the link for the inner/outer handle and latch lever release connects.
- 3. When the link connects, the latch lever releases by the inner and outer handle operation.

Double locking operation

- 1. The front door lock actuator rotates the built-in motor to the double locking side based on the double locking operation signal from the rear body control module (RBCM).
- 2. When the motor rotates to the double locking side, the connection of the door lock knob and front door lock link is disconnected.



Fail-safe

Function not equipped.