
#### **FUEL SYSTEM [SKYACTIV-D 2.2]**

id0114z7002600

#### **Outline**


• Fast-response, Piezo-electric type fuel injectors have been adopted which achieve highly precise fuel injection control.

# Structural view Engine compartment side L.H.D.



ac5wzn00002048


#### R.H.D.




ac5wzn00001918


## Fuel tank side

#### 2WD



## 4WD





#### ac5wzw00004752

#### **Structure**

• The fuel system consists of the following parts:

Part/System name		Reference	
Common rail injection system (See COMMON RAIL INJECTION SYSTEM [SKYACTIV-D 2.2].)	Fuel tank	(See FUEL TANK [SKYACTIV-D 2.2].)	
	Fuel filter	(See FUEL FILTER [SKYACTIV-D 2.2].)	
	Fuel warmer	(See FUEL WARMER [SKYACTIV-D 2.2].)	
	Supply pump	(See SUPPLY PUMP [SKYACTIV-D 2.2].)	
	Suction control valve	(See SUCTION CONTROL VALVE [SKYACTIV-D 2.2].)	
	Fuel check valve	(See FUEL CHECK VALVE [SKYACTIV-D 2.2].)	
	Fuel feed valve	(See FUEL FEED VALVE [SKYACTIV-D 2.2].)	
	Common rail	(See COMMON RAIL [SKYACTIV-D 2.2].)	
	Fuel pressure relief valve	(See FUEL PRESSURE RELIEF VALVE [SKYACTIV-D 2.2].)	
	Fuel injector	(See FUEL INJECTOR [SKYACTIV-D 2.2].)	
	Fuel pressure sensor	(See FUEL PRESSURE SENSOR [SKYACTIV-D 2.2].)	
	Fuel temperature sensor	(See FUEL TEMPERATURE SENSOR [SKYACTIV-D 2.2].)	
Non-return valve		(See NON-RETURN VALVE [SKYACTIV-D 2.2].)	
Sedimentor switch		(See SEDIMENTOR SWITCH [SKYACTIV-D 2.2].)	

# **Specification**

Item			Specification
Supply pump			Electric control
Fuel injector			Piezo-electric
Fuel tank capacity	(I (I IS got Imp goll))	2WD	56.0 {14.8, 12.3}
	(L {US gal, Imp gal})	4WD	58.0 {15.3, 12.8}
Fuel type			EN590 or the equivalent