DRIVE BELT [SKYACTIV-D 2.2]


id0110s5001100

Purpose, Function

• The drive belt transmits rotation force of the crankshaft pulley to the pulley for the auxiliary parts.


Construction

• The drive belt is installed to the front of the engine.



- · A V-ribbed belt has been adopted for the drive belt.
- With the adoption of the oil pressure type drive belt auto tensioner, the change in tension by the oil pressure damper operation is absorbed. As a result, the sliding resistance has been reduced by lowering the drive belt tension setting.

ac5wzn00001721



ac5jjn00001508