
## **BRAKE HOSE (FRONT) REMOVAL/INSTALLATION**

id041100190300

- 1. Remove in the order indicated in the table.
- 2. Install in the reverse order of removal.
- 3. After installation, add brake fluid, bleed the air, and inspect for fluid leakage. (See BRAKE FLUID AIR BLEEDING.)



| 1 | Brake pipe |
|---|------------|
| 2 | Clip       |
| 3 | Bolt       |

4 Brake hose