
## REAR CONSOLE DISASSEMBLY/ASSEMBLY

id091700898600

1. Disassemble in the order indicated in the table.



Ī	1	Screw A
ſ	2	Rear console bracket
Ī	3	Screw B
	4	Side panel
Ī	5	Rear console box
-		

2. Assemble in the reverse order of disassembly.

		ac5wzw0000145
6	Upper console	
7	Rear console cover	
8	Rear console lid	