

Syringe Too	ol Assembly
-------------	-------------


	<b>(1)</b>	Cre
	BY	Jos
		_


Created by: last edited:


Joshua Vasquez 7/2/2021


SCALE: 1:2


SHEET 1 OF 21














	C	-Ring Installati	on
		Created by:	last edited:
	ВУ	Joshua Vasquez	7/2/2021
		SCALE: 1:1	SHEET 3 OF 21






ITEM NO.	DESCRIPTION	QTY.
1	Syringe Tool Base with Inserts	1
2	M3 8mm Threaded Tool Balls	3
3	M3 Flathead Screw, 8mm long	3


Tool Ball Installation			
(CC_	(i)	Created by: Joshua Vasquez	last edited: 7/2/2021
	<u> </u>	SCALE: 1:1	SHEET 4 OF 21







ITEM NO.	DESCRIPTION	QTY.
3	Wedge Plate	1
4	M3 Flathead Screw, 8mm long	3

	Wedge Plate Installation			
(3)	<b>(</b> )	Created by: Joshua Vasquez	last edited: 7/2/2021	
		SCALE: 1:1	SHEET 5 OF 21	






These screws will hard-stop before fully screwing in. \




ITEM NO.	DESCRIPTION	QTY.
5	M3 Buttonhead Screw, 8mm long	4


	Retention Screw Installation			
60	<b>(1)</b>	Created by:	last edited:	
	BY	Joshua Vasquez	7/2/2021	
		SCALE: 1:1	SHEET 7 OF 21	



ITEM NO.	DESCRIPTION	QTY.
4	M3 Flathead Screw, 8mm long	10
7	Left O-Ring Wing with O-Rings	1
8	Right O-Ring Wing with O-Rings	1


Tool Wing Installation			
CC	<b>(</b> )	Created by: Joshua Vasquez	last edited: 7/2/2021
		SCALE: 1:2	SHEET 8 OF 21






ITEM NO.	DESCRIPTION	QTY.
1	Plunger Actuator	1
2	MGN9 Carriage Block	1
3	MGN9 Rail, 200mm	1
4	M3 Buttonhead Screw, 8mm long	4


Rail Assembly			
(c) (j)	Created by: Joshua Vasquez	last edited: 7/2/2021	
ВУ	SCALE: 1:2	SHEET 9 OF 21	






ITEM NO.	DESCRIPTION	QTY.
3	M3 Buttonhead Screw, 8mm long	3


Rail Installation			
CCC	<b>(</b> )	Created by: Joshua Vasquez	last edited: 7/2/2021
		SCALE: 1:2	SHEET 10 OF 21



ITEM NO.	DESCRIPTION	QTY.
1	T8x2 Leadscrew, 150mm long	1
2	8mm Nonmarring Clamp Collar	1
3	Printed Leadscrew Jig	1


Leadscrew Prep 1			
<u>(cc</u>	<b>(i)</b> BY	Created by: Joshua Vasquez	last edited: 7/2/2021
		SCALE: 1:2	SHEET 11 OF 21






ITEM NO.	DESCRIPTION	QTY.
3	8mm T8x2 Small Delrin Anti-Backlash Nut	1

Leadscrew Prep 2			
(00)	$\odot$	Created by:	last edited:
	BY	Joshua Vasquez	7/2/2021
		SCALE: 1:2	SHEET 12 OF 21




Compress this assembly by hand, and then tighten both set screws.




Turn this assembly by hand. It should have a minimal but consistent amount of resistance. If it feels like it is rubbing periodically, check to make sure the pulley is not seated at an angle.

ITEM NO.	DESCRIPTION	QTY.
1	3-piece, Thrust Bearing, 8mm Bore	2
2	2GT Pulley, 40T	1
3	Pulley Housing with inserts	1


Pulley Block Assembly			
(00)	<b>(i)</b>	Created by:	last edited:
	BY	Joshua Vasquez	7/2/2021
		SCALE: 5:8	SHEET 13 OF 21






ITEM	NO.	DESCRIPTION	QTY.
1		Nema 17 Motor Heatsink	1
2	·	LDO-42STH25-1404MAC Nema 17 Stepper Motor	1

Heatsink Installation			
(CC)	BY	Created by: Joshua Vasquez	last edited: 7/2/2021
		SCALE: 1:1	SHEET 14 OF 21







ITEM NO.	DESCRIPTION	QTY.
1	16-T 2GT Drive Pulley for 6mm belt	1
4	Drive Pulley Height Spacer	1
5	M3 Set Screw, 4mm len	2

Motor Pulley Installation			
	<b>(1)</b>	Created by:	last edited:
	ВУ	Joshua Vasquez	7/2/2021
		SCALE: 1:1	SHEET 15 OF 21


This Assembly is not necessary.

We will skip its inclusion in the subsequent steps.






The rest of the assembly will just use this minimal configuration.




CCC		<b>(</b> )	Created by: Joshua Vasquez	last edited: 7/2/2021
			SCALE: 1:1	SHEET 16 OF 21

Everything in this step will be loose until the next step.



ITEM NO.	DESCRIPTION	QTY.
1	M3 Socket Cap Screw, 40mm long	4
2	M3 Spacer, 18mm long	4
3	Pulley Block Assembly	1
4	Belt Retention Block	1
6	110T, 2GT Timing Belt, 6mm Tall	1



## Actuator Assembly 1/2


(cc)_	•	L <sub>i</sub>
	BY	J

Created by: last edited:

Joshua Vasquez 7/2/2021


SCALE: 3:4


**SHEET 17 OF 21** 





The motor screws rest in slots. When screwing in the motor assembly, pull it away from the big pulley to apply gentle tension on the belt. Fully tighten it this way.

Once tightened, check that the motor can spin freely without binding.












Shroud Installation			
	<b>(i)</b>	Created by:	last edited:
	BY	Joshua Vasquez	7/2/2021
		SCALE: 1:2	SHEET 19 OF 21



ITEM NO. DESCRIPTION		QTY.
1	Syringe Tool Base with Rail	1
2	Actuator Assembly	1
3	M3 Buttonhead Screw, 8mm long	2

Actuator Installation		
(i)	Created by:	last edited:
ВУ	Joshua Vasquez SCALE: 1:2	7/2/2021 SHEET 20 OF 21
	00/122: 1.2	01.1221 20 01 21





ITEM NO.	DESCRIPTION	QTY.
3	M3 Buttonhead Screw, 8mm long	6

## Leadscrew Attachment

CC	<b>(</b> )	Created by: Joshua Vasquez	last edited: 7/2/2021
		SCALE: 1:2	SHEET 21 OF 21