
7-1. Components on the Rear Case






7-2. Pre-requisite



7-3. Parts which must be changed after repair

BOM description & part code	KIT CODE	Image	Remarks
A/S-SVC TAPE BG WP OUTER (Common) [GH81-15404A]	A/S REWORK KIT-SM-G9600/G9608 (CHN/LA) [GH82-15974A]		Replace for Back Glass repair
A/S-SVC TAPE BG INNER NA (CHN/LA) [GH81-15406A]			
A/S-SVC TAPE BG INNER BTM NA (USA,CHN) [GH81-15415A]			
TAPE FINGER SENSOR WP [GH02-15815A]		,O	Replace for Back Glass Or Finger print sensor repair

7-4. Disassembly



- SOC 68%↓: 70 °C/10~20 minute

below heating condition

- SOC 68%↑: 70 °C/10~20 minute
- ** Please confirm the heating condition released lastly, and follow it.



Put the device in to HOT PLATE.(70°C/10mins)

Detach the Back Glass. And Finger sensor

1) Detach the left side of Back glass
2) Detach the Finger sensor connector





3

Unscrew 15 Point and disassemble SIM Tray from device



Caution
 Be care of scratch

Disassemble Upper Rear.

(Use disassemble hole left/right side of Rear to detach it)



Rear Top disassemble hole.

Caution
 Be care of Rear damage

X Caution

- 1) Be care of scratch
- 2) Be care of Rear and connector damage

Finally Disassemble Rear of bottom side.
(Use disassemble hole right—side of Rear to detach it)

6 Unscrew PBA 1points.





- ※ Caution
- 1) Be care of scratch
- 2) Be care of Rear and connector damage
- 3) Be careful not to damage the PBA

X Caution

Be careful not to damage the PBA

7 2 coaxial connector

2 coaxial cable, Battery connect and the other connectors. (7 Point)

8


Detach SUB PBA connector





- **X** Caution
- 1) Be care of scratch
- 2) Be care of connector/cable damage

- * Caution
- 1) Be care of FPCB damage
- 2) Be care of SUB PBA connector




13

Detach SUB PBA (2/4)

14

Detach SUB PBA (3/4)





※ Caution

Be care of SUB PBA damage

Caution

Be care of SUB PBA damage

15

Detach SUB PBA (2/4)



Disassemble Up side

X Caution


Be care of SUB PBA damage

7-5. Assembly

1 Attach SUB PBA and Ear jack on Front.

2 Screw 5point in SUB PBA.





Caution

Be care of coaxial cable damage


※ Caution

Be care of chip damage nearby screw point.

Attach components on Front. (TOP SPK, Sensor FPCB, Motor)

4


Attach PBA assy In Front Assy. (PBA+ Front)





- Caution
- 1) Be care of FPCB damage and tilt
- 2) Be care of press power/time

- Caution
- 1) Be care of Push SUB PBA connector.
- 2) Be care of components FPCB.



9 Unscrew 15 Point and disassemble SIM Tray from device

* Screw Torque: 1.3kgf



Attach the finger sensor on the REAR and Assemble the finger sensor on the PBA



***** Caution

Be care of scratch and REAR damage

※ Caution


Be care of scratch and tilt.


11

Attach the back glass inner tape on the backglass

12

Attach the finger tape on the back glass.





X Caution

Be care of scratch and tilt.

X Caution

Be care of scratch and tilt.

