7-1. Components on the Rear Case





7-2. Pre-requisite



7-3. Parts which must be changed after repair

BOM description & part code	KIT CODE	Image	Remarks
A/S-SVC TAPE BG WP OUTER (Common) [GH81-15875A]			Replace for
A/S-SVC TAPE BG INNER NA [GH81-15876A]	A/S REWORK KIT- SM-N960F [GH82-17460A]		Back Glass repair
TAPE FINGER SENSOR WP [GH02-16653A]			Replace for Back Glass Or Finger print sensor repair

7-4. Disassembly

- - Put the device in the chamber as following below heating condition
 - SOC 68%↓: 70 ℃/10~20 minute
 - SOC 68%↑: 70 °C/10~20 minute
 - * Please confirm the heating condition released lastly, and follow it.



Detach the Back Glass. And Finger sensor

1) Detach the left side of Back glass

2) Detach the Finger sensor connector





X Caution1) Be care of scratch

3

Unscrew 18 Point and disassemble SIM Tray from device



CautionBe care of Rear damage

CautionBe care of scratch

4 Disassemble Upper Rear.

(Use disassemble hole left/right side of Rear to detach it)



Rear Top disassemble hole.

※ Caution

- 1) Be care of scratch
- 2) Be care of Rear and connector damage

5

Finally Disassemble Rear of bottom side. (Use disassemble hole right side of Rear to detach it)

6

Unscrew PBA 3points.





- **※** Caution
- 1) Be care of scratch
- 2) Be care of Rear and connector damage
- 3) Be careful not to damage the PBA

- **X** Caution
- 1) Be careful not to damage the PBA

7

Disassemble 5 Point connector of PBA.



8

Detach other components.



- ※ Caution
- 1) Be care of scratch
- 2) Be care of connector/cable damage

- Caution
- 1) Be care of several kinds of damage

9

Detach Ear Jack

- 1) Unscrew PBA 1points.
- 2) Separation of Ear jack Module using Pinset.





10 De

Detach SUB PBA
1) Unscrew PBA 2points.

2) Separate sub PBA.



※ Caution

1) Be care of Ear jack connector

X Caution

1) Be care of SUB PBA damage

7-5. Assembly

1 Attach SUB PBA and Ear jack on Front.

2 Screw 3 point in SUB PBA.





***** Caution

※ Caution


1) Be care of chip damage nearby screw point.

Attach components on Front. (RCV module, Sensor FPCB, Motor, Battery)

4

Attach Front CAM, MAIN CAM and Iris CAM on PBA.





- Caution
- 1) Be care of FPCB damage and tilt
- 2) Be care of press power/time

- ***** Caution
- 1) Be care of press power/time


5

Assemble PBA to Front case. Battery connect and the other connectors. (5 Point)

* Torque Value: 1.2 ± 0.1kgfcm



Assemble the Bottom REAR in sequence.





- Caution
- 1) Be care of scratch and REAR damage
- 2) Check for contact damage.(red area)

Assemble the TOP+MID REAR Assy in sequence.

- Caution
- 1) Be care of scratch and REAR damage
- 2) Check for contact damage.(red area)
- 8

Screw insertion 18 Point.

* Torque Value: 1.2 ± 0.1 kgfcm



- 1) Be care of scratch and REAR damage
- 2) Check for contact damage.(red area)



- 1) Be care of Rear damage

9

Press the S-Pen cover using pressing jig and pad.

- Pressing force : 1 N


(It is set on the pressing jig in advance)

- Pressing tine : 5 sec

Attach the finger sensor on the REAR and Assemble the finger sensor on the PBA









X Caution

1) Do NOT press a S-Pen cover over 5 seconds to prevent display damage.

X Caution

1) Be care of scratch and tilt.

11

Attach the back glass inner tape on the back glass.

12

Attach the finger tape on the back glass.





※ Caution

1) Be care of scratch and tilt.

※ Caution

1) Be care of scratch and tilt.

13

Attach the back glass outside tape on the rear case.

Attach the back glass outside tape on the rear case by hands.

Gently press all adhesive parts of tape using disassembly stick or hands.







14 Attach the back glass on the REAR side.



Caution

1) Fit the tapes precisely to the screw and finger print sensor holes of rear case.

15

Press Back Glass.

- Pressing force : 1 N - Pressing time : 1 minute

SIM Tray must be seperated before pressing the backglass or the OCTA



Caution

1) Be care of scratch.

※ Caution

1) Be care of scratch and tilt.