
### 7-1. Components on the Rear Case





### 7-2. Pre-requisite



Confidential and proprietary-the contents in this service guide subject to change without prior notice Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

### 7-3. Parts which must be changed after repair

BOM description & part code	KIT code	Image	Remarks
Backglass Outside tape [GH81-16436A]	GH82-18798A		Replace for Backglass
Cam sealing tape [GH02-17355A]			
Mic sealing tape [GH02-07406A]			

#### 7-4. Disassembly

1

Put the device in the chamber as following below heating condition

- SOC 68%↓: 70 °C/10~20 minute

- SOC 68%↑: 60 °C/10~20 minute \* Please confirm the heating condition released lastly, and follow it.

2

Detach the Back Glass. Detach the left side of Back glass.





Caution

Be care of scratch.

**\*** Caution Be care of scratch.

3


Unscrew 15 Point and disassemble SIM Tray from device.

4

Disassemble Upper Rear. (Use disassemble hole left/right side of Rear to detach it)







Rear Top disassemble hole.

Caution

Be care of Rear damage.


- **\*** Caution
- 1) Be care of scratch.
- 2) Be care of Rear and connector damage.

Confidential and proprietary-the contents in this service guide subject to change without prior notice Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

Finally Disassemble Rear of bottom side.
(Use disassemble hole right side of Rear to detach it)

6 Un

Unscrew PBA 3points.





- Caution
- 1) Be care of scratch.
- 2) Be care of Rear and connector damage.
- 3) Be careful not to damage the PBA.

Caution

Be careful not to damage the PBA.

7

Battery connect and the other connectors. (5 Point).

8

Detach Ear Jack.





- Caution
- 1) Be care of scratch.
- 2) Be care of connector damage.

- Caution
- 1) Be care of FPCB damage.
- 2) Be care of Ear jack connector.

2) Be care of Front CAM connector.




Confidential and proprietary-the contents in this service guide subject to change without prior notice Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

#### 7-5. Assembly

1

Assemble PBA on Front. About 30 degrees will be inserted into the PBA. 2

Battery connect and the other connectors. (5 Point)





Caution

Be care of FPCB damage.

Caution

Be care of FPCB and Y-OCTA damage.

3

Screw 3 Point s of the PBA (\* Torque value : 1.3kgf)

4

Assemble the Bottom REAR in sequence.






Caution

Be careful not to damage the PBA.

Caution

Be care of scratch and REAR damage

Confidential and proprietary-the contents in this service guide subject to change without prior notice Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.





Screw 15points of the Front. And Insert sim tray

( \* Torque : 1.3 kgf)





Caution
 Be care of scratch and REAR damage.

Caution
Be care of scratch and REAR damage.

7 Assemble backglass.



6

Press Back Glass.
Pressing force : 1 N
Pressing time : 1 minute



Caution
Be care of scratch and tilt.

Caution
 Be care of scratch.

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.