
7. Level 2 Repair

7-1. Components on the Rear Case




7-2. Pre-requisite




7-3. Parts which must be changed after repair

BOM Discription	Picture Picture	Remarks
A/S-MAIN WINDOW TAPE_R/KIT [GH02-10746A]		Replace when repair Front part
A/S-Touch Key Ass'y_R/KIT)		
[GH96-08865A]		

7-4. Disassembly





7-5. Aassembly



Assemble REAR Ass'y and Front ass'y

6

Assemble LCD ass'y and REAR ass'y



Caution

1) Be care of Torque:1.2 Kgf+Cm

- *** Caution**
- 1. Insert LCD Connector into the bracket hole correctly.
- 2. Insert RCV deco into the TSP hole correctly.
- 3. Attach LCD ass' y and Bracket ass' y.

Assemble LCD CAP

8

Press OCTA



Idam



*** Caution**

1) Be care of Scratch

*** Caution**

1) Be care of force and time