5. MAIN Electrical Parts List

[SM-A205FN]

| Parts Code | Design LOC | Description |
|-------------|----------------------|-----------------|
| 0401-001110 | D5001 | DIODE-SWITCHING |
| 0404-001250 | D5000 | DIODE-SCHOTTKY |
| 0406-001506 | ZD1001,ZD1002 | DIODE-TVS |
| 0406-001561 | ZD5002,ZD5011,ZD6000 | DIODE-TVS |
| 0406-001561 | ZD6001,ZD6026 | DIODE-TVS |
| 0406-001592 | ZD5004,ZD6021 | DIODE-TVS |
| 0406-001728 | ZD5001 | DIODE-TVS |
| 0406-001781 | ZD6024,ZD6025 | DIODE-TVS |
| 0406-001809 | ZD6015,ZD6016 | DIODE-TVS |
| 0406-001837 | D6000 | DIODE-TVS |
| 0505-003618 | Q5000 | FET-SILICON |
| 0601-003768 | LED5000 | LED |
| 1001-001974 | U1003 | IC |
| 1001-001975 | U2002,U2006,U2007 | IC |
| 1001-002078 | U2003 | IC |
| 1003-002802 | U2004 | IC |
| 1105-002962 | UCP400UP | RAM(POP) |
| 1107-002552 | UME5000 | IC-FLASH MEMORY |
| 1201-003869 | U3005 | IC |
| 1201-003984 | U1002,U1005 | IC |
| 1201-004100 | U1006 | IC |
| 1201-004209 | PAM1000 | IC |
| 1201-004228 | U6001 | IC |
| 1203-008249 | U3011 | IC |
| 1203-008475 | U6002 | IC |
| 1203-008603 | U5007 | IC |
| 1203-008693 | U2001 | IC |
| 1203-008771 | U3015 | IC |
| 1203-008867 | U3000,U7003 | IC |
| 1203-008872 | U7002,U7004 | IC |
| 1203-008925 | U3013 | IC |
| 1203-008989 | U7000 | IC |
| 1203-009220 | U7001 | IC |
| 1203-009211 | U5002 | IC |
| 1203-009213 | U5001 | IC |
| 1203-009221 | U7005 | IC |
| 1205-005806 | U2012 | IC |

5. MAIN Electrical Parts List

| 1205-005860 | U3003 | IC |
|-------------|----------------------|------------|
| 1205-006088 | U3004 | IC |
| 1205-006117 | UCP400 | IC |
| 1209-002413 | U3014 | IC |
| 1209-002450 | U3012 | IC |
| 1209-002629 | U3016 | IC |
| 1404-001724 | TH1000,TH4000,VR5000 | THERMISTOR |
| 1405-001429 | V7000 | VARISTOR |
| 2007-000141 | R3005,R3012,R3014 | R-CHIP |
| 2007-003015 | R6062,R6063 | R-CHIP |
| 2007-007190 | R6064,R6067 | R-CHIP |
| 2007-007310 | R3001,R3002 | R-CHIP |
| 2007-007741 | R4012,R5025,R5027 | R-CHIP |
| 2007-007741 | R6061 | R-CHIP |
| 2007-007798 | R6025 | R-CHIP |
| 2007-007942 | R5000 | R-CHIP |
| 2007-007946 | R5004 | R-CHIP |
| 2007-008052 | R5022,R5024,R7001 | R-CHIP |
| 2007-008052 | R7009 | R-CHIP |
| 2007-008055 | R4001,R4010,R4047 | R-CHIP |
| 2007-008419 | R4041,R5023 | R-CHIP |
| 2007-008483 | R5020,R5021 | R-CHIP |
| 2007-008516 | R3003,R4015,R4016 | R-CHIP |
| 2007-008516 | R4027,R4226,R6003 | R-CHIP |
| 2007-008516 | R6023,R6024 | R-CHIP |
| 2007-008531 | R5015,R6009,R7000 | R-CHIP |
| 2007-008531 | R7004,R7014 | R-CHIP |
| 2007-008588 | R3006,R3007,R4017 | R-CHIP |
| 2007-008588 | R4018,R4022,R4023 | R-CHIP |
| 2007-008588 | R4024,R4026,R4030 | R-CHIP |
| 2007-008588 | R4032,R4034,R4036 | R-CHIP |
| 2007-008588 | R4037,R4228,R4231 | R-CHIP |
| 2007-008588 | R4334,R4335,R4336 | R-CHIP |
| 2007-008800 | R6012 | R-CHIP |
| 2007-008806 | R2001 | R-CHIP |
| 2007-009084 | R6000 | R-CHIP |
| 2007-009111 | R3004,R5029 | R-CHIP |
| 2007-009157 | R1007,R4002,R4003 | R-CHIP |
| 2007-009157 | R5009,R5105,R6026 | R-CHIP |

5. MAIN Electrical Parts List

| 2007-009171 | R5003,R5008 | R-CHIP |
|-------------|-------------------|----------------|
| 2007-009212 | R5011,R6006 | R-CHIP |
| 2007-009352 | R5019 | R-CHIP |
| 2007-009361 | R1000,R1002 | R-CHIP |
| 2007-009408 | R6007 | R-CHIP |
| 2007-009410 | R6038,R6039 | R-CHIP |
| 2007-009766 | R3000 | R-CHIP |
| 2007-009793 | R6014 | R-CHIP |
| 2007-009801 | R5007 | R-CHIP |
| 2007-009805 | R1001,R1003,R1004 | R-CHIP |
| 2007-009920 | R4004,R4005,R4007 | R-CHIP |
| 2007-009920 | R4009 | R-CHIP |
| 2007-009969 | R6008 | R-CHIP |
| 2007-010685 | R7003 | R-CHIP |
| 2007-011043 | R4200,R4201,R4202 | R-CHIP |
| 2007-011043 | R4203,R4333 | R-CHIP |
| 2007-011532 | R6010 | R-CHIP |
| 2007-011648 | R6019 | R-CHIP |
| 2007-012068 | R5002 | R-CHIP |
| 2203-000330 | C3050 | C-CERAMIC,CHIP |
| 2203-000489 | C5173,C5174 | C-CERAMIC,CHIP |
| 2203-001153 | C3044,C3052 | C-CERAMIC,CHIP |
| 2203-001239 | C3049 | C-CERAMIC,CHIP |
| 2203-005344 | C5267 | C-CERAMIC,CHIP |
| 2203-005682 | C5117,C5123,C5556 | C-CERAMIC,CHIP |
| 2203-005725 | C7006,L1038 | C-CERAMIC,CHIP |
| 2203-005729 | C6000,C6004,C6010 | C-CERAMIC,CHIP |
| 2203-005729 | C6015,C6018,C6019 | C-CERAMIC,CHIP |
| 2203-005729 | C7011 | C-CERAMIC,CHIP |
| 2203-005731 | C1125,C2055,C6058 | C-CERAMIC,CHIP |
| 2203-005731 | C6059 | C-CERAMIC,CHIP |
| 2203-005732 | C5049,C6009,C6016 | C-CERAMIC,CHIP |
| 2203-005732 | C6017,C6022 | C-CERAMIC,CHIP |
| 2203-005734 | C3057 | C-CERAMIC,CHIP |
| 2203-005736 | C1000,C1003,C1006 | C-CERAMIC,CHIP |
| 2203-005736 | C1017,C1018,C1022 | C-CERAMIC,CHIP |
| 2203-005736 | C1034,C1040,C1052 | C-CERAMIC,CHIP |
| 2203-005736 | C1053,C1060,C1083 | C-CERAMIC,CHIP |
| 2203-005736 | C1084,C1085,C1091 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-005736 | C1114,C2002,C2004 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-005736 | C2006,C2014,C2030 | C-CERAMIC,CHIP |
| 2203-005736 | C2036,C2041,C2047 | C-CERAMIC,CHIP |
| 2203-005736 | C2050,C3003,C3007 | C-CERAMIC,CHIP |
| 2203-005736 | C3014,C3028,C3029 | C-CERAMIC,CHIP |
| 2203-005736 | C3054,C3061,L1008 | C-CERAMIC,CHIP |
| 2203-005736 | L1044 | C-CERAMIC,CHIP |
| 2203-005740 | C3036 | C-CERAMIC,CHIP |
| 2203-005777 | C1086,C1093 | C-CERAMIC,CHIP |
| 2203-005789 | C1025,C1116,C1117 | C-CERAMIC,CHIP |
| 2203-005789 | C1118,C1119,C1120 | C-CERAMIC,CHIP |
| 2203-005789 | C1126,C1142,L1026 | C-CERAMIC,CHIP |
| 2203-005792 | C1078,C1095,C1139 | C-CERAMIC,CHIP |
| 2203-005792 | C2003 | C-CERAMIC,CHIP |
| 2203-005806 | C1099,C1106,C1108 | C-CERAMIC,CHIP |
| 2203-005806 | C2000,C3030 | C-CERAMIC,CHIP |
| 2203-006121 | C6014 | C-CERAMIC,CHIP |
| 2203-006187 | C6029 | C-CERAMIC,CHIP |
| 2203-006194 | C6008 | C-CERAMIC,CHIP |
| 2203-006305 | L2009 | C-CERAMIC,CHIP |
| 2203-006318 | C1077,L1064,L2032 | C-CERAMIC,CHIP |
| 2203-006379 | C6060 | C-CERAMIC,CHIP |
| 2203-006400 | C1011,C2048,C3039 | C-CERAMIC,CHIP |
| 2203-006400 | C3043,C3053,C4013 | C-CERAMIC,CHIP |
| 2203-006400 | C6051 | C-CERAMIC,CHIP |
| 2203-006410 | C1087 | C-CERAMIC,CHIP |
| 2203-006423 | C2032,C3066,C3098 | C-CERAMIC,CHIP |
| 2203-006423 | C3099,C4005,C5120 | C-CERAMIC,CHIP |
| 2203-006423 | C5172,C5555,C6013 | C-CERAMIC,CHIP |
| 2203-006423 | C6026,C6028,C7034 | C-CERAMIC,CHIP |
| 2203-006556 | C1036,C3058,C5045 | C-CERAMIC,CHIP |
| 2203-006604 | C1104,C3062,C6030 | C-CERAMIC,CHIP |
| 2203-006611 | C1081 | C-CERAMIC,CHIP |
| 2203-006648 | C6021 | C-CERAMIC,CHIP |
| 2203-006665 | L1059 | C-CERAMIC,CHIP |
| 2203-006668 | C4064 | C-CERAMIC,CHIP |
| 2203-006674 | C2042,C3027 | C-CERAMIC,CHIP |
| 2203-006707 | C1008 | C-CERAMIC,CHIP |
| 2203-006839 | C1012,C1048,C1068 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-006839 | C1071,C1074,C1131 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-006839 | C2001,C4035,C5092 | C-CERAMIC,CHIP |
| 2203-006839 | C5095 | C-CERAMIC,CHIP |
| 2203-006846 | C1111,C4204,C4205 | C-CERAMIC,CHIP |
| 2203-006846 | C4206,C4207 | C-CERAMIC,CHIP |
| 2203-006979 | C2010,C2018,C2020 | C-CERAMIC,CHIP |
| 2203-006979 | C2022,C2024,C2026 | C-CERAMIC,CHIP |
| 2203-006979 | C2028,C2033,C2054 | C-CERAMIC,CHIP |
| 2203-007194 | C1014,C3059,C3067 | C-CERAMIC,CHIP |
| 2203-007194 | C7007 | C-CERAMIC,CHIP |
| 2203-007210 | C4050,C4051,C4068 | C-CERAMIC,CHIP |
| 2203-007210 | C4087,C5125,C5126 | C-CERAMIC,CHIP |
| 2203-007235 | C5038,C5058 | C-CERAMIC,CHIP |
| 2203-007271 | C2053,C4062,C5083 | C-CERAMIC,CHIP |
| 2203-007271 | C5097,C5129,C7064 | C-CERAMIC,CHIP |
| 2203-007279 | C7012,C7147 | C-CERAMIC,CHIP |
| 2203-007317 | C3020,C3021,C7014 | C-CERAMIC,CHIP |
| 2203-007391 | C2031,C5133,C5136 | C-CERAMIC,CHIP |
| 2203-007392 | C5061,C5098 | C-CERAMIC,CHIP |
| 2203-007393 | C1105,C2012,C3011 | C-CERAMIC,CHIP |
| 2203-007393 | C3100,C3101,C4011 | C-CERAMIC,CHIP |
| 2203-007393 | C4023,C4024,C4039 | C-CERAMIC,CHIP |
| 2203-007393 | C4074,C4078,C5032 | C-CERAMIC,CHIP |
| 2203-007393 | C5066,C5084,C5087 | C-CERAMIC,CHIP |
| 2203-007393 | C5096,C5118,C5124 | C-CERAMIC,CHIP |
| 2203-007393 | C5127,C5168,C5169 | C-CERAMIC,CHIP |
| 2203-007393 | C5170,C5171,C6025 | C-CERAMIC,CHIP |
| 2203-007393 | C7003,C7018,C7023 | C-CERAMIC,CHIP |
| 2203-007393 | C7024,C7027,C7028 | C-CERAMIC,CHIP |
| 2203-007393 | C7133 | C-CERAMIC,CHIP |
| 2203-007456 | C5086,C6032 | C-CERAMIC,CHIP |
| 2203-007474 | C2017,C2021,C2023 | C-CERAMIC,CHIP |
| 2203-007474 | C2027,C2034,C4047 | C-CERAMIC,CHIP |
| 2203-007474 | C4049,C4069,C5056 | C-CERAMIC,CHIP |
| 2203-007796 | C2011,C2019,C2025 | C-CERAMIC,CHIP |
| 2203-007796 | C2049,C3000,C3002 | C-CERAMIC,CHIP |
| 2203-007796 | C3008,C3013,C3018 | C-CERAMIC,CHIP |
| 2203-007796 | C3022,C3031,C3094 | C-CERAMIC,CHIP |
| 2203-007796 | C3096,C3097,C3102 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-007796 | C4002,C4004,C4006 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-007796 | C4007,C4008,C4009 | C-CERAMIC,CHIP |
| 2203-007796 | C4014,C4015,C4018 | C-CERAMIC,CHIP |
| 2203-007796 | C4019,C4020,C4021 | C-CERAMIC,CHIP |
| 2203-007796 | C4022,C4029,C4030 | C-CERAMIC,CHIP |
| 2203-007796 | C4033,C4034,C4037 | C-CERAMIC,CHIP |
| 2203-007796 | C4038,C4044,C4045 | C-CERAMIC,CHIP |
| 2203-007796 | C4052,C4053,C4055 | C-CERAMIC,CHIP |
| 2203-007796 | C4056,C4063,C4065 | C-CERAMIC,CHIP |
| 2203-007796 | C4066,C4067,C4070 | C-CERAMIC,CHIP |
| 2203-007796 | C4071,C4072,C4073 | C-CERAMIC,CHIP |
| 2203-007796 | C4075,C4076,C4077 | C-CERAMIC,CHIP |
| 2203-007796 | C4079,C4080,C4081 | C-CERAMIC,CHIP |
| 2203-007796 | C4082,C4083,C4088 | C-CERAMIC,CHIP |
| 2203-007796 | C4089,C4090,C4091 | C-CERAMIC,CHIP |
| 2203-007796 | C4092,C4093,C4094 | C-CERAMIC,CHIP |
| 2203-007796 | C4259,C5008,C5009 | C-CERAMIC,CHIP |
| 2203-007796 | C5012,C5014,C5015 | C-CERAMIC,CHIP |
| 2203-007796 | C5016,C5017,C5018 | C-CERAMIC,CHIP |
| 2203-007796 | C5019,C5020,C5024 | C-CERAMIC,CHIP |
| 2203-007796 | C5025,C5026,C5030 | C-CERAMIC,CHIP |
| 2203-007796 | C5073,C5085,C5093 | C-CERAMIC,CHIP |
| 2203-007796 | C5101,C5102,C5104 | C-CERAMIC,CHIP |
| 2203-007796 | C5107,C5108,C5110 | C-CERAMIC,CHIP |
| 2203-007796 | C5128,C5166,C7005 | C-CERAMIC,CHIP |
| 2203-007796 | C7013,C7015,C7025 | C-CERAMIC,CHIP |
| 2203-007796 | C7026,C7033,C7041 | C-CERAMIC,CHIP |
| 2203-007796 | C7065,C7066,C7068 | C-CERAMIC,CHIP |
| 2203-007796 | C7144,C7145 | C-CERAMIC,CHIP |
| 2203-008097 | C6054 | C-CERAMIC,CHIP |
| 2203-008158 | C5079 | C-CERAMIC,CHIP |
| 2203-008242 | C2058,C3005,C3016 | C-CERAMIC,CHIP |
| 2203-008242 | C4001,C4003,C4017 | C-CERAMIC,CHIP |
| 2203-008242 | C4043,C5000,C5002 | C-CERAMIC,CHIP |
| 2203-008242 | C5004,C5007,C5011 | C-CERAMIC,CHIP |
| 2203-008242 | C5021,C5022,C5023 | C-CERAMIC,CHIP |
| 2203-008242 | C5027,C5036,C6053 | C-CERAMIC,CHIP |
| 2203-008242 | C7031,C7152 | C-CERAMIC,CHIP |
| 2203-008654 | C6031 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-008860 | C2057,C3006,C3092 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-008860 | C3093,C3095,C5100 | C-CERAMIC,CHIP |
| 2203-008860 | C5121,C5134,C6056 | C-CERAMIC,CHIP |
| 2203-008860 | C7032,C7040,C7042 | C-CERAMIC,CHIP |
| 2203-008860 | C7067,C7069,C7070 | C-CERAMIC,CHIP |
| 2203-008876 | C1069,C1098,C3010 | C-CERAMIC,CHIP |
| 2203-008876 | C5075,C5119,C6057 | C-CERAMIC,CHIP |
| 2203-008876 | C7029,C7030,C7188 | C-CERAMIC,CHIP |
| 2203-009167 | C3048,C3051 | C-CERAMIC,CHIP |
| 2203-009328 | C4060,C4061,C4086 | C-CERAMIC,CHIP |
| 2203-009328 | C5039,C5041,C5042 | C-CERAMIC,CHIP |
| 2203-009328 | C5047,C5052,C5060 | C-CERAMIC,CHIP |
| 2203-009328 | C5063,C5074 | C-CERAMIC,CHIP |
| 2203-009537 | C5003 | C-CERAMIC,CHIP |
| 2203-009618 | C5069,C5077,C6006 | C-CERAMIC,CHIP |
| 2203-009618 | C6055,C7044 | C-CERAMIC,CHIP |
| 2203-009733 | C1075,C2009,C3025 | C-CERAMIC,CHIP |
| 2203-009733 | C3026,C3035,C5035 | C-CERAMIC,CHIP |
| 2203-009733 | C5037,C5040,C5043 | C-CERAMIC,CHIP |
| 2203-009733 | C5048,C5050,C5051 | C-CERAMIC,CHIP |
| 2203-009733 | C5054,C5055,C5065 | C-CERAMIC,CHIP |
| 2203-009733 | C5071,C5072,C5076 | C-CERAMIC,CHIP |
| 2203-009733 | C5081,C5091,C5152 | C-CERAMIC,CHIP |
| 2203-009733 | C6052,C7045,C7046 | C-CERAMIC,CHIP |
| 2203-009733 | C7047,C7048,C7049 | C-CERAMIC,CHIP |
| 2203-009733 | C7050,C7051,C7054 | C-CERAMIC,CHIP |
| 2203-009733 | C7055,C7056,C7060 | C-CERAMIC,CHIP |
| 2203-009733 | C7061,C7062,C7148 | C-CERAMIC,CHIP |
| 2203-009733 | C7150,C7151 | C-CERAMIC,CHIP |
| 2203-010085 | C5044 | C-CERAMIC,CHIP |
| 2703-002649 | L1033,L2029 | INDUCTOR-SMD |
| 2703-002903 | L3013,L6010,L6011 | INDUCTOR-SMD |
| 2703-002907 | C1096,L2031 | INDUCTOR-SMD |
| 2703-002955 | L2020 | INDUCTOR-SMD |
| 2703-002959 | L2028,L3011 | INDUCTOR-SMD |
| 2703-002999 | C1112,L1005,L3027 | INDUCTOR-SMD |
| 2703-003476 | L3000 | INDUCTOR-SMD |
| 2703-003970 | L3014 | INDUCTOR-SMD |
| 2703-004012 | L1035,L1054,L1061 | INDUCTOR-SMD |

5. MAIN Electrical Parts List

| 2703-004012 | L2024 | INDUCTOR-SMD |
|-------------|-------------------|--------------|
| 2703-004013 | L1028,L3015 | INDUCTOR-SMD |
| 2703-004014 | L2022,L2023,L3010 | INDUCTOR-SMD |
| 2703-004018 | C1057,C1127,L1007 | INDUCTOR-SMD |
| 2703-004018 | L1055,L1060 | INDUCTOR-SMD |
| 2703-004032 | C1092,L1032 | INDUCTOR-SMD |
| 2703-004034 | C1051,C2046,L1025 | INDUCTOR-SMD |
| 2703-004034 | L1029,L3002 | INDUCTOR-SMD |
| 2703-004035 | L2001,L2004,L2038 | INDUCTOR-SMD |
| 2703-004036 | C1129,L1011,L3004 | INDUCTOR-SMD |
| 2703-004037 | L2000,L2003,L2035 | INDUCTOR-SMD |
| 2703-004038 | C1063,C3040,L1023 | INDUCTOR-SMD |
| 2703-004038 | L1057,L2010 | INDUCTOR-SMD |
| 2703-004171 | L1016 | INDUCTOR-SMD |
| 2703-004193 | L1003 | INDUCTOR-SMD |
| 2703-004286 | C1059,C3038,L1010 | INDUCTOR-SMD |
| 2703-004286 | L1062 | INDUCTOR-SMD |
| 2703-004317 | L1013,L3001 | INDUCTOR-SMD |
| 2703-004328 | L1004,L1052,L2002 | INDUCTOR-SMD |
| 2703-004328 | L2007 | INDUCTOR-SMD |
| 2703-004363 | L2030 | INDUCTOR-SMD |
| 2703-004367 | L3016 | INDUCTOR-SMD |
| 2703-004368 | L3003 | INDUCTOR-SMD |
| 2703-004408 | L1017,L1021 | INDUCTOR-SMD |
| 2703-004763 | C1137,C1140,L1001 | INDUCTOR-SMD |
| 2703-004763 | L1053 | INDUCTOR-SMD |
| 2703-005066 | L2008 | INDUCTOR-SMD |
| 2703-005085 | L1063 | INDUCTOR-SMD |
| 2703-005087 | L1030,L1037 | INDUCTOR-SMD |
| 2703-005200 | L6012 | INDUCTOR-SMD |
| 2703-005201 | L5001,L5003,L5004 | INDUCTOR-SMD |
| 2703-005201 | L5005,L5011 | INDUCTOR-SMD |
| 2703-005224 | L7009 | INDUCTOR-SMD |
| 2703-005296 | L1041 | INDUCTOR-SMD |
| 2703-005366 | C1124 | INDUCTOR-SMD |
| 2703-005418 | L7006 | INDUCTOR-SMD |
| 2703-005419 | L7007 | INDUCTOR-SMD |
| 2703-005555 | L3008,L3009 | INDUCTOR-SMD |
| 2703-005689 | L5002,L5006,L5007 | INDUCTOR-SMD |

5. MAIN Electrical Parts List

| 2703-005689 | L5009,L5012 | INDUCTOR-SMD |
|-------------|-------------------|---------------------|
| 2801-005389 | OSC5000 | CRYSTAL-UNIT |
| 2805-001117 | OSC2000 | OSCILLATOR |
| 2901-001690 | C4057,C4058,C4059 | FILTER-EMI SMD |
| 2901-001690 | C4084,C4085,U4009 | FILTER-EMI SMD |
| 2901-001690 | U4010 | FILTER-EMI SMD |
| 2904-002198 | F2002 | FILTER-SAW |
| 2904-002339 | F2000 | FILTER-SAW |
| 2904-002350 | F1008 | FILTER-SAW |
| 2904-002355 | F3002,F3003 | FILTER-SAW |
| 2904-002381 | F3000 | FILTER-SAW |
| 2904-002397 | F1006,F2001 | FILTER-SAW |
| 2910-000367 | F1010 | FILTER |
| 2911-000430 | U2000 | FILTER |
| 2911-000450 | U1007 | FILTER |
| 3003-001237 | MIC6000 | MIC-CONDENSOR |
| 3301-002078 | R6011 | CORE-FERRITE BEAD |
| 3301-002122 | L2005,L2006,L6008 | CORE-FERRITE BEAD |
| 3301-002122 | L6018 | CORE-FERRITE BEAD |
| 3301-002223 | L7000,L7001,L7002 | CORE-FERRITE BEAD |
| 3301-002223 | L7004 | CORE-FERRITE BEAD |
| 3301-002235 | L6001,L6003,L6004 | CORE-FERRITE BEAD |
| 3301-002235 | L6005,L6006,L6007 | CORE-FERRITE BEAD |
| 3301-002235 | L6009,L6013 | CORE-FERRITE BEAD |
| 3301-002237 | L1000,L2027,L2037 | CORE-FERRITE BEAD |
| 3301-002238 | L2013,L2017,L2019 | CORE-FERRITE BEAD |
| 3301-002238 | L3012,L6000,L6002 | CORE-FERRITE BEAD |
| 3301-002239 | L2011 | CORE-FERRITE BEAD |
| 3301-002242 | L2036 | CORE-FERRITE BEAD |
| 3301-002312 | L2014,L2016,L2018 | CORE-FERRITE BEAD |
| 3301-002312 | L7005,L7008,L7010 | CORE-FERRITE BEAD |
| 3301-002331 | L5008 | CORE-FERRITE BEAD |
| 3705-001937 | RFS1000,RFS1001 | CONNECTOR-COAXIAL |
| 3709-001932 | SIM4UP | CONNECTOR-CARD EDGE |
| 3709-001933 | SIM3 | CONNECTOR-CARD EDGE |
| 3709-001934 | SIM1,SIM2 | CONNECTOR-CARD EDGE |
| 3710-003193 | SOC7000 | CONNECTOR-SOCKET |
| 3710-003985 | SOC6000 | CONNECTOR-SOCKET |
| 3711-007107 | HDC7002 | CONNECTOR-HEADER |

5. MAIN Electrical Parts List

| 3711-007295 | HDC7001 | CONNECTOR-HEADER |
|-------------|-----------------|------------------|
| 3711-008511 | HDC7003 | CONNECTOR-HEADER |
| 3711-008847 | BTC5000 | CONNECTOR-HEADER |
| 3711-008997 | HEA5000 | CONNECTOR-HEADER |
| 3712-001621 | ANT2000,ANT2001 | CONNECTOR |
| 3712-001621 | ANT2002,ANT2003 | CONNECTOR |
| 3712-001621 | ANT2004,ANT2008 | CONNECTOR |
| 3712-001621 | ANT5000,ANT5001 | CONNECTOR |
| 3712-001621 | ANT5003,ANT5004 | CONNECTOR |
| 3712-001621 | ANT5006 | CONNECTOR |
| 3712-001626 | ANT2006,ANT2009 | CONNECTOR |
| 3712-001633 | ANT3001,ANT3004 | CONNECTOR |
| 3712-001633 | ANT5002,ANT5005 | CONNECTOR |
| 3712-001666 | ANT6000,ANT6001 | CONNECTOR |
| 3712-001714 | ANT3000,ANT3002 | CONNECTOR |
| 4709-002196 | F2004 | RF-MODULE |
| 4709-002412 | F1000,F1001 | RF-MODULE |
| GH02-18335A | SC6005SP | EMI SHEET |
| GH61-08634A | CON1000 | C-CLIP |
| GH62-00042A | GA7000 | GASKET |
| GH63-16268A | SC6000 | SHIELDCAN |
| GH63-16890A | SC6002 | SHIELDCAN |
| GH63-16937A | SC6003 | SHIELDCAN |
| GH63-16938A | SC6004 | SHIELDCAN |
| GH98-44134A | SC6005 | SHIELDCAN |

5. MAIN Electrical Parts List

[SM-A205F]

| Parts Code | Design LOC | Description |
|-------------|----------------------|-----------------|
| 0401-001110 | D5001 | DIODE-SWITCHING |
| 0404-001250 | D5000 | DIODE-SCHOTTKY |
| 0406-001506 | ZD1001,ZD1002 | DIODE-TVS |
| 0406-001561 | ZD5002,ZD5011,ZD6000 | DIODE-TVS |
| 0406-001561 | ZD6001,ZD6026 | DIODE-TVS |
| 0406-001592 | ZD5004,ZD6021 | DIODE-TVS |
| 0406-001728 | ZD5001 | DIODE-TVS |
| 0406-001781 | ZD6024,ZD6025 | DIODE-TVS |
| 0406-001809 | ZD6015,ZD6016 | DIODE-TVS |
| 0406-001837 | D6000 | DIODE-TVS |
| 0505-003618 | Q5000 | FET-SILICON |
| 0601-003768 | LED5000 | LED |
| 1001-001974 | U1003 | IC |
| 1001-001975 | U2002,U2006,U2007 | IC |
| 1001-002078 | U2003 | IC |
| 1003-002802 | U2004 | IC |
| 1105-002962 | UCP400UP | RAM(POP) |
| 1107-002552 | UME5000 | IC-FLASH MEMORY |
| 1201-003869 | U3005 | IC |
| 1201-003984 | U1002,U1005 | IC |
| 1201-004100 | U1006 | IC |
| 1201-004209 | PAM1000 | IC |
| 1201-004228 | U6001 | IC |
| 1203-008249 | U3011 | IC |
| 1203-008475 | U6002 | IC |
| 1203-008603 | U5007 | IC |
| 1203-008693 | U2001 | IC |
| 1203-008771 | U3015 | IC |
| 1203-008867 | U7003 | IC |
| 1203-008872 | U7002,U7004 | IC |
| 1203-008925 | U3013 | IC |
| 1203-008989 | U7000 | IC |
| 1203-009211 | U5002 | IC |
| 1203-009213 | U5001 | IC |
| 1203-009220 | U7001 | IC |
| 1203-009221 | U7005 | IC |
| 1205-005806 | U2012 | IC |

5. MAIN Electrical Parts List

| 1205-005860 | U3003 | IC |
|-------------|----------------------|------------|
| 1205-006117 | UCP400 | IC |
| 1209-002413 | U3014 | IC |
| 1209-002450 | U3012 | IC |
| 1209-002629 | U3016 | IC |
| 1404-001724 | TH1000,TH4000,VR5000 | THERMISTOR |
| 1405-001429 | V7000 | VARISTOR |
| 2007-000141 | R3005,R3012,R3014 | R-CHIP |
| 2007-003015 | R6062,R6063 | R-CHIP |
| 2007-007190 | R6064,R6067 | R-CHIP |
| 2007-007741 | R4013,R5025,R5027 | R-CHIP |
| 2007-007741 | R6061 | R-CHIP |
| 2007-007798 | R6025 | R-CHIP |
| 2007-007942 | R5000 | R-CHIP |
| 2007-007946 | R5004 | R-CHIP |
| 2007-008052 | R5022,R5024,R7001 | R-CHIP |
| 2007-008052 | R7009 | R-CHIP |
| 2007-008055 | R4001,R4010,R4047 | R-CHIP |
| 2007-008419 | R4041,R5023 | R-CHIP |
| 2007-008483 | R5020,R5021 | R-CHIP |
| 2007-008516 | R3003,R4015,R4016 | R-CHIP |
| 2007-008516 | R4027,R4226,R6003 | R-CHIP |
| 2007-008516 | R6023,R6024 | R-CHIP |
| 2007-008531 | R5015,R6009,R7000 | R-CHIP |
| 2007-008531 | R7004,R7014 | R-CHIP |
| 2007-008588 | R4017,R4018,R4022 | R-CHIP |
| 2007-008588 | R4023,R4024,R4026 | R-CHIP |
| 2007-008588 | R4030,R4032,R4034 | R-CHIP |
| 2007-008588 | R4036,R4037,R4228 | R-CHIP |
| 2007-008588 | R4231,R4334,R4335 | R-CHIP |
| 2007-008588 | R4336 | R-CHIP |
| 2007-008800 | R6012 | R-CHIP |
| 2007-008806 | R2001 | R-CHIP |
| 2007-009084 | R6000 | R-CHIP |
| 2007-009111 | R3004,R5029 | R-CHIP |
| 2007-009157 | R1007,R4002,R4003 | R-CHIP |
| 2007-009157 | R5009,R5105,R6026 | R-CHIP |
| 2007-009171 | R5003,R5008 | R-CHIP |
| 2007-009212 | R5011,R6006 | R-CHIP |

5. MAIN Electrical Parts List

| 2007-009352 | R5019 | R-CHIP |
|-------------|-------------------|----------------|
| 2007-009361 | R1000,R1002 | R-CHIP |
| 2007-009408 | R6007 | R-CHIP |
| 2007-009410 | R6038,R6039 | R-CHIP |
| 2007-009766 | R3000 | R-CHIP |
| 2007-009793 | R6014 | R-CHIP |
| 2007-009801 | R5007 | R-CHIP |
| 2007-009805 | R1001,R1003,R1004 | R-CHIP |
| 2007-009920 | R4004,R4005,R4007 | R-CHIP |
| 2007-009920 | R4009 | R-CHIP |
| 2007-009969 | R6008 | R-CHIP |
| 2007-010685 | R7003 | R-CHIP |
| 2007-011043 | R4200,R4201,R4202 | R-CHIP |
| 2007-011043 | R4203,R4333 | R-CHIP |
| 2007-011532 | R6010 | R-CHIP |
| 2007-011648 | R6019 | R-CHIP |
| 2007-012068 | R5002 | R-CHIP |
| 2203-000489 | C5173,C5174 | C-CERAMIC,CHIP |
| 2203-005344 | C5267 | C-CERAMIC,CHIP |
| 2203-005682 | C5117,C5123,C5556 | C-CERAMIC,CHIP |
| 2203-005725 | C7006,L1038 | C-CERAMIC,CHIP |
| 2203-005729 | C6000,C6004,C6010 | C-CERAMIC,CHIP |
| 2203-005729 | C6015,C6018,C6019 | C-CERAMIC,CHIP |
| 2203-005729 | C7011 | C-CERAMIC,CHIP |
| 2203-005731 | C1125,C2055,C6058 | C-CERAMIC,CHIP |
| 2203-005731 | C6059 | C-CERAMIC,CHIP |
| 2203-005732 | C5049,C6009,C6016 | C-CERAMIC,CHIP |
| 2203-005732 | C6017,C6022 | C-CERAMIC,CHIP |
| 2203-005734 | C3057 | C-CERAMIC,CHIP |
| 2203-005736 | C1000,C1003,C1006 | C-CERAMIC,CHIP |
| 2203-005736 | C1017,C1018,C1022 | C-CERAMIC,CHIP |
| 2203-005736 | C1034,C1040,C1052 | C-CERAMIC,CHIP |
| 2203-005736 | C1053,C1060,C1083 | C-CERAMIC,CHIP |
| 2203-005736 | C1084,C1085,C1091 | C-CERAMIC,CHIP |
| 2203-005736 | C1114,C2002,C2004 | C-CERAMIC,CHIP |
| 2203-005736 | C2006,C2014,C2030 | C-CERAMIC,CHIP |
| 2203-005736 | C2036,C2041,C2047 | C-CERAMIC,CHIP |
| 2203-005736 | C2050,C3003,C3007 | C-CERAMIC,CHIP |
| 2203-005736 | C3014,C3028,C3029 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-005736 | C3054,C3061,L1008 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-005736 | L1044 | C-CERAMIC,CHIP |
| 2203-005740 | C3036 | C-CERAMIC,CHIP |
| 2203-005777 | C1086,C1093 | C-CERAMIC,CHIP |
| 2203-005789 | C1025,C1116,C1117 | C-CERAMIC,CHIP |
| 2203-005789 | C1118,C1119,C1120 | C-CERAMIC,CHIP |
| 2203-005789 | C1126,C1142,L1026 | C-CERAMIC,CHIP |
| 2203-005792 | C1078,C1095,C1139 | C-CERAMIC,CHIP |
| 2203-005792 | C2003 | C-CERAMIC,CHIP |
| 2203-005806 | C1099,C1106,C1108 | C-CERAMIC,CHIP |
| 2203-005806 | C2000 | C-CERAMIC,CHIP |
| 2203-006121 | C6014 | C-CERAMIC,CHIP |
| 2203-006187 | C6029 | C-CERAMIC,CHIP |
| 2203-006194 | C6008 | C-CERAMIC,CHIP |
| 2203-006305 | L2009 | C-CERAMIC,CHIP |
| 2203-006318 | C1077,L1064,L2032 | C-CERAMIC,CHIP |
| 2203-006379 | C6060 | C-CERAMIC,CHIP |
| 2203-006400 | C1011,C2048,C3039 | C-CERAMIC,CHIP |
| 2203-006400 | C4013,C6051 | C-CERAMIC,CHIP |
| 2203-006410 | C1087 | C-CERAMIC,CHIP |
| 2203-006423 | C2032,C3066,C3098 | C-CERAMIC,CHIP |
| 2203-006423 | C3099,C4005,C5120 | C-CERAMIC,CHIP |
| 2203-006423 | C5172,C5555,C6013 | C-CERAMIC,CHIP |
| 2203-006423 | C6026,C6028,C7034 | C-CERAMIC,CHIP |
| 2203-006556 | C1036,C3058,C5045 | C-CERAMIC,CHIP |
| 2203-006604 | C1104,C3062,C6030 | C-CERAMIC,CHIP |
| 2203-006611 | C1081 | C-CERAMIC,CHIP |
| 2203-006648 | C6021 | C-CERAMIC,CHIP |
| 2203-006665 | L1059 | C-CERAMIC,CHIP |
| 2203-006668 | C4064 | C-CERAMIC,CHIP |
| 2203-006674 | C2042,C3027 | C-CERAMIC,CHIP |
| 2203-006707 | C1008 | C-CERAMIC,CHIP |
| 2203-006839 | C1012,C1048,C1068 | C-CERAMIC,CHIP |
| 2203-006839 | C1071,C1074,C1131 | C-CERAMIC,CHIP |
| 2203-006839 | C2001,C4035,C5092 | C-CERAMIC,CHIP |
| 2203-006839 | C5095 | C-CERAMIC,CHIP |
| 2203-006846 | C1111,C4204,C4205 | C-CERAMIC,CHIP |
| 2203-006846 | C4206,C4207 | C-CERAMIC,CHIP |
| 2203-006979 | C2010,C2018,C2020 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-006979 | C2022,C2024,C2026 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-006979 | C2028,C2033,C2054 | C-CERAMIC,CHIP |
| 2203-007194 | C1014,C3059,C3067 | C-CERAMIC,CHIP |
| 2203-007194 | C7007 | C-CERAMIC,CHIP |
| 2203-007210 | C4050,C4051,C4068 | C-CERAMIC,CHIP |
| 2203-007210 | C4087,C5125,C5126 | C-CERAMIC,CHIP |
| 2203-007235 | C5038,C5058 | C-CERAMIC,CHIP |
| 2203-007271 | C2053,C4062,C5083 | C-CERAMIC,CHIP |
| 2203-007271 | C5097,C5129,C7064 | C-CERAMIC,CHIP |
| 2203-007279 | C7012,C7147 | C-CERAMIC,CHIP |
| 2203-007317 | C7014 | C-CERAMIC,CHIP |
| 2203-007391 | C2031,C5133,C5136 | C-CERAMIC,CHIP |
| 2203-007392 | C5061,C5098 | C-CERAMIC,CHIP |
| 2203-007393 | C1105,C2012,C3011 | C-CERAMIC,CHIP |
| 2203-007393 | C3100,C3101,C4011 | C-CERAMIC,CHIP |
| 2203-007393 | C4023,C4024,C4039 | C-CERAMIC,CHIP |
| 2203-007393 | C4074,C4078,C5032 | C-CERAMIC,CHIP |
| 2203-007393 | C5066,C5084,C5087 | C-CERAMIC,CHIP |
| 2203-007393 | C5096,C5118,C5124 | C-CERAMIC,CHIP |
| 2203-007393 | C5127,C5168,C5169 | C-CERAMIC,CHIP |
| 2203-007393 | C5170,C5171,C6025 | C-CERAMIC,CHIP |
| 2203-007393 | C7003,C7018,C7023 | C-CERAMIC,CHIP |
| 2203-007393 | C7024,C7027,C7028 | C-CERAMIC,CHIP |
| 2203-007393 | C7133 | C-CERAMIC,CHIP |
| 2203-007456 | C5086,C6032 | C-CERAMIC,CHIP |
| 2203-007474 | C2017,C2021,C2023 | C-CERAMIC,CHIP |
| 2203-007474 | C2027,C2034,C4047 | C-CERAMIC,CHIP |
| 2203-007474 | C4049,C4069,C5056 | C-CERAMIC,CHIP |
| 2203-007796 | C2011,C2019,C2025 | C-CERAMIC,CHIP |
| 2203-007796 | C2049,C3000,C3008 | C-CERAMIC,CHIP |
| 2203-007796 | C3013,C3018,C3094 | C-CERAMIC,CHIP |
| 2203-007796 | C3096,C3097,C3102 | C-CERAMIC,CHIP |
| 2203-007796 | C4002,C4004,C4006 | C-CERAMIC,CHIP |
| 2203-007796 | C4007,C4008,C4009 | C-CERAMIC,CHIP |
| 2203-007796 | C4014,C4015,C4018 | C-CERAMIC,CHIP |
| 2203-007796 | C4019,C4020,C4021 | C-CERAMIC,CHIP |
| 2203-007796 | C4022,C4029,C4030 | C-CERAMIC,CHIP |
| 2203-007796 | C4033,C4034,C4037 | C-CERAMIC,CHIP |
| 2203-007796 | C4038,C4044,C4045 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-007796 | C4052,C4053,C4055 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-007796 | C4056,C4063,C4065 | C-CERAMIC,CHIP |
| 2203-007796 | C4066,C4067,C4070 | C-CERAMIC,CHIP |
| 2203-007796 | C4071,C4072,C4073 | C-CERAMIC,CHIP |
| 2203-007796 | C4075,C4076,C4077 | C-CERAMIC,CHIP |
| 2203-007796 | C4079,C4080,C4081 | C-CERAMIC,CHIP |
| 2203-007796 | C4082,C4083,C4088 | C-CERAMIC,CHIP |
| 2203-007796 | C4089,C4090,C4091 | C-CERAMIC,CHIP |
| 2203-007796 | C4092,C4093,C4094 | C-CERAMIC,CHIP |
| 2203-007796 | C4259,C5008,C5009 | C-CERAMIC,CHIP |
| 2203-007796 | C5012,C5014,C5015 | C-CERAMIC,CHIP |
| 2203-007796 | C5016,C5017,C5018 | C-CERAMIC,CHIP |
| 2203-007796 | C5019,C5020,C5024 | C-CERAMIC,CHIP |
| 2203-007796 | C5025,C5026,C5030 | C-CERAMIC,CHIP |
| 2203-007796 | C5073,C5085,C5093 | C-CERAMIC,CHIP |
| 2203-007796 | C5101,C5102,C5104 | C-CERAMIC,CHIP |
| 2203-007796 | C5107,C5108,C5110 | C-CERAMIC,CHIP |
| 2203-007796 | C5128,C5166,C7005 | C-CERAMIC,CHIP |
| 2203-007796 | C7013,C7015,C7025 | C-CERAMIC,CHIP |
| 2203-007796 | C7026,C7033,C7041 | C-CERAMIC,CHIP |
| 2203-007796 | C7065,C7066,C7068 | C-CERAMIC,CHIP |
| 2203-007796 | C7144,C7145 | C-CERAMIC,CHIP |
| 2203-008097 | C6054 | C-CERAMIC,CHIP |
| 2203-008158 | C5079 | C-CERAMIC,CHIP |
| 2203-008242 | C2058,C3005,C3016 | C-CERAMIC,CHIP |
| 2203-008242 | C4001,C4003,C4017 | C-CERAMIC,CHIP |
| 2203-008242 | C4043,C5000,C5002 | C-CERAMIC,CHIP |
| 2203-008242 | C5004,C5007,C5011 | C-CERAMIC,CHIP |
| 2203-008242 | C5021,C5022,C5023 | C-CERAMIC,CHIP |
| 2203-008242 | C5027,C5036,C6053 | C-CERAMIC,CHIP |
| 2203-008242 | C7031,C7152 | C-CERAMIC,CHIP |
| 2203-008654 | C6031 | C-CERAMIC,CHIP |
| 2203-008860 | C2057,C3092,C3093 | C-CERAMIC,CHIP |
| 2203-008860 | C3095,C5100,C5121 | C-CERAMIC,CHIP |
| 2203-008860 | C5134,C6056,C7032 | C-CERAMIC,CHIP |
| 2203-008860 | C7040,C7042,C7067 | C-CERAMIC,CHIP |
| 2203-008860 | C7069,C7070 | C-CERAMIC,CHIP |
| 2203-008876 | C1069,C1098,C3010 | C-CERAMIC,CHIP |
| 2203-008876 | C5075,C5119,C6057 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-008876 | C7029,C7030,C7188 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-009328 | C4060,C4061,C4086 | C-CERAMIC,CHIP |
| 2203-009328 | C5039,C5041,C5042 | C-CERAMIC,CHIP |
| 2203-009328 | C5047,C5052,C5060 | C-CERAMIC,CHIP |
| 2203-009328 | C5063,C5074 | C-CERAMIC,CHIP |
| 2203-009537 | C5003 | C-CERAMIC,CHIP |
| 2203-009618 | C5069,C5077,C6006 | C-CERAMIC,CHIP |
| 2203-009618 | C6055,C7044 | C-CERAMIC,CHIP |
| 2203-009733 | C1075,C2009,C5035 | C-CERAMIC,CHIP |
| 2203-009733 | C5037,C5040,C5043 | C-CERAMIC,CHIP |
| 2203-009733 | C5048,C5050,C5051 | C-CERAMIC,CHIP |
| 2203-009733 | C5054,C5055,C5065 | C-CERAMIC,CHIP |
| 2203-009733 | C5071,C5072,C5076 | C-CERAMIC,CHIP |
| 2203-009733 | C5081,C5091,C5152 | C-CERAMIC,CHIP |
| 2203-009733 | C6052,C7045,C7046 | C-CERAMIC,CHIP |
| 2203-009733 | C7047,C7048,C7049 | C-CERAMIC,CHIP |
| 2203-009733 | C7050,C7051,C7054 | C-CERAMIC,CHIP |
| 2203-009733 | C7055,C7056,C7060 | C-CERAMIC,CHIP |
| 2203-009733 | C7061,C7062,C7148 | C-CERAMIC,CHIP |
| 2203-009733 | C7150,C7151 | C-CERAMIC,CHIP |
| 2203-010085 | C5044 | C-CERAMIC,CHIP |
| 2703-002649 | L1033,L2029 | INDUCTOR-SMD |
| 2703-002903 | L3013,L6010,L6011 | INDUCTOR-SMD |
| 2703-002907 | C1096,L2031 | INDUCTOR-SMD |
| 2703-002955 | L2020 | INDUCTOR-SMD |
| 2703-002959 | L2028,L3011 | INDUCTOR-SMD |
| 2703-002999 | C1112,L1005,L3027 | INDUCTOR-SMD |
| 2703-003476 | L3000 | INDUCTOR-SMD |
| 2703-003970 | L3014 | INDUCTOR-SMD |
| 2703-004012 | L1035,L1054,L1061 | INDUCTOR-SMD |
| 2703-004012 | L2024 | INDUCTOR-SMD |
| 2703-004013 | L1028,L3015 | INDUCTOR-SMD |
| 2703-004014 | L2022,L2023,L3010 | INDUCTOR-SMD |
| 2703-004018 | C1057,C1127,L1007 | INDUCTOR-SMD |
| 2703-004018 | L1055,L1060 | INDUCTOR-SMD |
| 2703-004032 | C1092,L1032 | INDUCTOR-SMD |
| 2703-004034 | C1051,C2046,L1025 | INDUCTOR-SMD |
| 2703-004034 | L1029,L3002 | INDUCTOR-SMD |
| 2703-004035 | L2001,L2004,L2038 | INDUCTOR-SMD |

5. MAIN Electrical Parts List

| 2703-004036 | C1129,L1011,L3004 | INDUCTOR-SMD |
|-------------|-------------------|----------------|
| 2703-004037 | L2000,L2003,L2035 | INDUCTOR-SMD |
| 2703-004038 | C1063,C3040,L1023 | INDUCTOR-SMD |
| 2703-004038 | L1057,L2010 | INDUCTOR-SMD |
| 2703-004171 | L1016 | INDUCTOR-SMD |
| 2703-004193 | L1003 | INDUCTOR-SMD |
| 2703-004286 | C1059,C3038,L1010 | INDUCTOR-SMD |
| 2703-004286 | L1062 | INDUCTOR-SMD |
| 2703-004317 | L1013,L3001 | INDUCTOR-SMD |
| 2703-004328 | L1004,L1052,L2002 | INDUCTOR-SMD |
| 2703-004328 | L2007 | INDUCTOR-SMD |
| 2703-004363 | L2030 | INDUCTOR-SMD |
| 2703-004367 | L3016 | INDUCTOR-SMD |
| 2703-004368 | L3003 | INDUCTOR-SMD |
| 2703-004408 | L1017,L1021 | INDUCTOR-SMD |
| 2703-004763 | C1137,C1140,L1001 | INDUCTOR-SMD |
| 2703-004763 | L1053 | INDUCTOR-SMD |
| 2703-005066 | L2008 | INDUCTOR-SMD |
| 2703-005085 | L1063 | INDUCTOR-SMD |
| 2703-005087 | L1030,L1037 | INDUCTOR-SMD |
| 2703-005200 | L6012 | INDUCTOR-SMD |
| 2703-005201 | L5001,L5003,L5004 | INDUCTOR-SMD |
| 2703-005201 | L5005,L5011 | INDUCTOR-SMD |
| 2703-005224 | L7009 | INDUCTOR-SMD |
| 2703-005296 | L1041 | INDUCTOR-SMD |
| 2703-005366 | C1124 | INDUCTOR-SMD |
| 2703-005418 | L7006 | INDUCTOR-SMD |
| 2703-005419 | L7007 | INDUCTOR-SMD |
| 2703-005689 | L5002,L5006,L5007 | INDUCTOR-SMD |
| 2703-005689 | L5009,L5012 | INDUCTOR-SMD |
| 2801-005389 | OSC5000 | CRYSTAL-UNIT |
| 2805-001117 | OSC2000 | OSCILLATOR |
| 2901-001690 | C4057,C4058,C4059 | FILTER-EMI SMD |
| 2901-001690 | C4084,C4085,U4009 | FILTER-EMI SMD |
| 2901-001690 | U4010 | FILTER-EMI SMD |
| 2904-002198 | F2002 | FILTER-SAW; |
| 2904-002339 | F2000 | FILTER-SAW; |
| 2904-002350 | F1008 | FILTER-SAW; |
| 2904-002355 | F3002,F3003 | FILTER-SAW; |

5. MAIN Electrical Parts List

| 2904-002381 | F3000 | FILTER-SAW; |
|-------------|-------------------|---------------------|
| 2904-002397 | F1006,F2001 | FILTER-SAW; |
| 2910-000367 | F1010 | FILTER |
| 2911-000430 | U2000 | FILTER |
| 2911-000450 | U1007 | FILTER |
| 3003-001237 | MIC6000 | MIC-CONDENSOR |
| 3301-002078 | R6011 | CORE-FERRITE BEAD |
| 3301-002122 | L2005,L2006,L6008 | CORE-FERRITE BEAD |
| 3301-002122 | L6018 | CORE-FERRITE BEAD |
| 3301-002223 | L7000,L7001,L7002 | CORE-FERRITE BEAD |
| 3301-002223 | L7004 | CORE-FERRITE BEAD |
| 3301-002235 | L6001,L6003,L6004 | CORE-FERRITE BEAD |
| 3301-002235 | L6005,L6006,L6007 | CORE-FERRITE BEAD |
| 3301-002235 | L6009,L6013 | CORE-FERRITE BEAD |
| 3301-002237 | L1000,L2027,L2037 | CORE-FERRITE BEAD |
| 3301-002238 | L2013,L2017,L2019 | CORE-FERRITE BEAD |
| 3301-002238 | L3012,L6000,L6002 | CORE-FERRITE BEAD |
| 3301-002239 | L2011 | CORE-FERRITE BEAD |
| 3301-002242 | L2036 | CORE-FERRITE BEAD |
| 3301-002312 | L2014,L2016,L2018 | CORE-FERRITE BEAD |
| 3301-002312 | L7005,L7008,L7010 | CORE-FERRITE BEAD |
| 3301-002331 | L5008 | CORE-FERRITE BEAD |
| 3705-001937 | RFS1000,RFS1001 | CONNECTOR-COAXIAL |
| 3709-001932 | SIM4UP | CONNECTOR-CARD EDGE |
| 3709-001933 | SIM3 | CONNECTOR-CARD EDGE |
| 3709-001934 | SIM1,SIM2 | CONNECTOR-CARD EDGE |
| 3710-003193 | SOC7000 | CONNECTOR-SOCKET |
| 3710-003985 | SOC6000 | CONNECTOR-SOCKET |
| 3711-007107 | HDC7002 | CONNECTOR-HEADER |
| 3711-007295 | HDC7001 | CONNECTOR-HEADER |
| 3711-008511 | HDC7003 | CONNECTOR-HEADER |
| 3711-008847 | BTC5000 | CONNECTOR-HEADER |
| 3711-008997 | HEA5000 | CONNECTOR-HEADER |
| 3712-001621 | ANT2000,ANT2001 | CONNECTOR |
| 3712-001621 | ANT2002,ANT2003 | CONNECTOR |
| 3712-001621 | ANT2004,ANT2008 | CONNECTOR |
| 3712-001621 | ANT5000,ANT5001 | CONNECTOR |
| 3712-001621 | ANT5003,ANT5004 | CONNECTOR |
| 3712-001621 | ANT5006 | CONNECTOR |

5. MAIN Electrical Parts List

| 0710 001000 | ANITORNO ANITORNO | CONNECTOR |
|-------------|-------------------|-----------|
| 3712-001626 | ANT2006,ANT2009 | |
| 3712-001633 | ANT5002,ANT5005 | CONNECTOR |
| 3712-001666 | ANT6000,ANT6001 | CONNECTOR |
| 3712-001714 | ANT3000,ANT3002 | CONNECTOR |
| 4709-002196 | F2004 | RF-MODULE |
| 4709-002412 | F1000,F1001 | RF-MODULE |
| GH02-18335A | SC6005SP | EMI SHEET |
| GH61-08634A | CON1000 | C-CLIP |
| GH62-00042A | GA7000 | GASKET |
| GH63-16268A | SC6000 | SHIELDCAN |
| GH63-16890A | SC6002 | SHIELDCAN |
| GH63-16937A | SC6003 | SHIELDCAN |
| GH63-16938A | SC6004 | SHIELDCAN |
| GH98-44134A | SC6005 | SHIELDCAN |

5. MAIN Electrical Parts List

[SM-A205G]

| Parts Code | Design LOC | Description |
|-------------|----------------------|-----------------|
| 0401-001110 | D5001 | DIODE-SWITCHING |
| 0404-001250 | D5000 | DIODE-SCHOTTKY |
| 0406-001506 | ZD1001,ZD1002 | DIODE-TVS |
| 0406-001561 | ZD5002,ZD5011,ZD6000 | DIODE-TVS |
| 0406-001561 | ZD6001,ZD6026 | DIODE-TVS |
| 0406-001592 | ZD5004,ZD6021 | DIODE-TVS |
| 0406-001728 | ZD5001 | DIODE-TVS |
| 0406-001781 | ZD6024,ZD6025 | DIODE-TVS |
| 0406-001809 | ZD6015,ZD6016 | DIODE-TVS |
| 0406-001837 | D6000 | DIODE-TVS |
| 0505-003618 | Q5000 | FET-SILICON |
| 0601-003768 | LED5000 | LED |
| 1001-001974 | U1003 | IC |
| 1001-001975 | U1009,U2002,U2006 | IC |
| 1001-001975 | U2007 | IC |
| 1001-002078 | U2003 | IC |
| 1003-002802 | U2004 | IC |
| 1105-002962 | UCP400UP | RAM(POP) |
| 1107-002552 | UME5000 | IC-FLASH MEMORY |
| 1201-003869 | U3005 | IC |
| 1201-003984 | U1002,U1005 | IC |
| 1201-004100 | U1006 | IC |
| 1201-004209 | PAM1000 | IC |
| 1201-004228 | U6001 | IC |
| 1203-008249 | U3011 | IC |
| 1203-008475 | U6002 | IC |
| 1203-008603 | U5007 | IC |
| 1203-008693 | U2001 | IC |
| 1203-008771 | U3015 | IC |
| 1203-008867 | U7003 | IC |
| 1203-008872 | U7002,U7004 | IC |
| 1203-008925 | U3013 | IC |
| 1203-008989 | U7000 | IC |
| 1203-009211 | U5002 | IC |
| 1203-009213 | U5001 | IC |
| 1203-009220 | U7001 | IC |
| 1203-009221 | U7005 | IC |

5. MAIN Electrical Parts List

| 1205-005806 | U2012 | IC |
|-------------|----------------------|------------|
| 1205-005860 | U3003 | IC |
| 1205-006117 | UCP400 | IC |
| 1209-002413 | U3014 | IC |
| 1209-002450 | U3012 | IC |
| 1209-002629 | U3016 | IC |
| 1404-001724 | TH1000,TH4000,VR5000 | THERMISTOR |
| 1405-001429 | V7000 | VARISTOR |
| 2007-000141 | R3005,R3012,R3014 | R-CHIP |
| 2007-003015 | R6062,R6063 | R-CHIP |
| 2007-007190 | R6064,R6067 | R-CHIP |
| 2007-007741 | R4013,R5025,R5027 | R-CHIP |
| 2007-007741 | R6061 | R-CHIP |
| 2007-007798 | R6025 | R-CHIP |
| 2007-007942 | R5000 | R-CHIP |
| 2007-007946 | R5004 | R-CHIP |
| 2007-008052 | R5022,R5024,R7001 | R-CHIP |
| 2007-008052 | R7009 | R-CHIP |
| 2007-008055 | R4001,R4010,R4047 | R-CHIP |
| 2007-008419 | R4041,R5023 | R-CHIP |
| 2007-008483 | R5020,R5021 | R-CHIP |
| 2007-008516 | R3003,R4015,R4016 | R-CHIP |
| 2007-008516 | R4027,R4226,R6003 | R-CHIP |
| 2007-008516 | R6023,R6024 | R-CHIP |
| 2007-008531 | R5015,R6009,R7000 | R-CHIP |
| 2007-008531 | R7004,R7014 | R-CHIP |
| 2007-008588 | R4017,R4018,R4022 | R-CHIP |
| 2007-008588 | R4023,R4024,R4026 | R-CHIP |
| 2007-008588 | R4030,R4032,R4034 | R-CHIP |
| 2007-008588 | R4036,R4037,R4228 | R-CHIP |
| 2007-008588 | R4231,R4334,R4335 | R-CHIP |
| 2007-008588 | R4336 | R-CHIP |
| 2007-008800 | R6012 | R-CHIP |
| 2007-008806 | R2001 | R-CHIP |
| 2007-009084 | R6000 | R-CHIP |
| 2007-009111 | R3004,R5029 | R-CHIP |
| 2007-009157 | R1007,R4002,R4003 | R-CHIP |
| 2007-009157 | R5009,R5105,R6026 | R-CHIP |
| 2007-009171 | R5003,R5008 | R-CHIP |

5. MAIN Electrical Parts List

| 2007-009212 | R5011,R6006 | R-CHIP |
|-------------|-------------------|----------------|
| 2007-009352 | R5019 | R-CHIP |
| 2007-009361 | R1000,R1002 | R-CHIP |
| 2007-009408 | R6007 | R-CHIP |
| 2007-009410 | R6038,R6039 | R-CHIP |
| 2007-009766 | R3000 | R-CHIP |
| 2007-009793 | R6014 | R-CHIP |
| 2007-009801 | R5007 | R-CHIP |
| 2007-009805 | R1001,R1003,R1004 | R-CHIP |
| 2007-009920 | R4004,R4005,R4007 | R-CHIP |
| 2007-009920 | R4009 | R-CHIP |
| 2007-009969 | R6008 | R-CHIP |
| 2007-010685 | R7003 | R-CHIP |
| 2007-011043 | R4200,R4201,R4202 | R-CHIP |
| 2007-011043 | R4203,R4333 | R-CHIP |
| 2007-011532 | R6010 | R-CHIP |
| 2007-011648 | R6019 | R-CHIP |
| 2007-012068 | R5002 | R-CHIP |
| 2203-000489 | C5173,C5174 | C-CERAMIC,CHIP |
| 2203-005344 | C5267 | C-CERAMIC,CHIP |
| 2203-005682 | C5117,C5123,C5556 | C-CERAMIC,CHIP |
| 2203-005725 | C1133,C7006,L1038 | C-CERAMIC,CHIP |
| 2203-005727 | C1123,C1132 | C-CERAMIC,CHIP |
| 2203-005729 | C6000,C6004,C6010 | C-CERAMIC,CHIP |
| 2203-005729 | C6015,C6018,C6019 | C-CERAMIC,CHIP |
| 2203-005729 | C7011 | C-CERAMIC,CHIP |
| 2203-005731 | C1125,C2055,C6058 | C-CERAMIC,CHIP |
| 2203-005731 | C6059 | C-CERAMIC,CHIP |
| 2203-005732 | C5049,C6009,C6016 | C-CERAMIC,CHIP |
| 2203-005732 | C6017,C6022 | C-CERAMIC,CHIP |
| 2203-005734 | C3057 | C-CERAMIC,CHIP |
| 2203-005736 | C1000,C1003,C1006 | C-CERAMIC,CHIP |
| 2203-005736 | C1017,C1018,C1022 | C-CERAMIC,CHIP |
| 2203-005736 | C1028,C1034,C1040 | C-CERAMIC,CHIP |
| 2203-005736 | C1052,C1053,C1060 | C-CERAMIC,CHIP |
| 2203-005736 | C1072,C1083,C1084 | C-CERAMIC,CHIP |
| 2203-005736 | C1085,C1091,C1114 | C-CERAMIC,CHIP |
| 2203-005736 | C1141,C2002,C2004 | C-CERAMIC,CHIP |
| 2203-005736 | C2006,C2014,C2030 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-005736 | C2036,C2041,C2047 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-005736 | C2050,C3003,C3007 | C-CERAMIC,CHIP |
| 2203-005736 | C3014,C3028,C3029 | C-CERAMIC,CHIP |
| 2203-005736 | C3054,C3061,L1008 | C-CERAMIC,CHIP |
| 2203-005736 | L1044 | C-CERAMIC,CHIP |
| 2203-005740 | C3036 | C-CERAMIC,CHIP |
| 2203-005777 | C1086,C1089,C1093 | C-CERAMIC,CHIP |
| 2203-005777 | C1113 | C-CERAMIC,CHIP |
| 2203-005789 | C1025,C1103,C1116 | C-CERAMIC,CHIP |
| 2203-005789 | C1117,C1118,C1119 | C-CERAMIC,CHIP |
| 2203-005789 | C1120,C1126,C1142 | C-CERAMIC,CHIP |
| 2203-005789 | L1026 | C-CERAMIC,CHIP |
| 2203-005792 | C1078,C1095,C1110 | C-CERAMIC,CHIP |
| 2203-005792 | C1122,C1139,C2003 | C-CERAMIC,CHIP |
| 2203-005806 | C1099,C1106,C1108 | C-CERAMIC,CHIP |
| 2203-005806 | C2000 | C-CERAMIC,CHIP |
| 2203-006121 | C6014 | C-CERAMIC,CHIP |
| 2203-006187 | C6029 | C-CERAMIC,CHIP |
| 2203-006194 | C6008 | C-CERAMIC,CHIP |
| 2203-006305 | C1107,L2009 | C-CERAMIC,CHIP |
| 2203-006318 | C1077,C1088,L1064 | C-CERAMIC,CHIP |
| 2203-006318 | L2032 | C-CERAMIC,CHIP |
| 2203-006379 | C6060 | C-CERAMIC,CHIP |
| 2203-006400 | C1002,C1011,C2048 | C-CERAMIC,CHIP |
| 2203-006400 | C3039,C4013,C6051 | C-CERAMIC,CHIP |
| 2203-006410 | C1087 | C-CERAMIC,CHIP |
| 2203-006423 | C2032,C3066,C3098 | C-CERAMIC,CHIP |
| 2203-006423 | C3099,C4005,C5120 | C-CERAMIC,CHIP |
| 2203-006423 | C5172,C5555,C6013 | C-CERAMIC,CHIP |
| 2203-006423 | C6026,C6028,C7034 | C-CERAMIC,CHIP |
| 2203-006556 | C1036,C3058,C5045 | C-CERAMIC,CHIP |
| 2203-006604 | C1104,C3062,C6030 | C-CERAMIC,CHIP |
| 2203-006611 | C1081,C1109 | C-CERAMIC,CHIP |
| 2203-006648 | C6021 | C-CERAMIC,CHIP |
| 2203-006665 | L1059 | C-CERAMIC,CHIP |
| 2203-006668 | C4064 | C-CERAMIC,CHIP |
| 2203-006674 | C2042,C3027 | C-CERAMIC,CHIP |
| 2203-006707 | C1008 | C-CERAMIC,CHIP |
| 2203-006839 | C1012,C1048,C1068 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-006839 | C1071,C1074,C1131 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-006839 | C1136,C2001,C4035 | C-CERAMIC,CHIP |
| 2203-006839 | C5092,C5095 | C-CERAMIC,CHIP |
| 2203-006846 | C1111,C4204,C4205 | C-CERAMIC,CHIP |
| 2203-006846 | C4206,C4207 | C-CERAMIC,CHIP |
| 2203-006979 | C2010,C2018,C2020 | C-CERAMIC,CHIP |
| 2203-006979 | C2022,C2024,C2026 | C-CERAMIC,CHIP |
| 2203-006979 | C2028,C2033,C2054 | C-CERAMIC,CHIP |
| 2203-007194 | C1014,C3059,C3067 | C-CERAMIC,CHIP |
| 2203-007194 | C7007 | C-CERAMIC,CHIP |
| 2203-007210 | C4050,C4051,C4068 | C-CERAMIC,CHIP |
| 2203-007210 | C4087,C5125,C5126 | C-CERAMIC,CHIP |
| 2203-007235 | C5038,C5058 | C-CERAMIC,CHIP |
| 2203-007271 | C2053,C4062,C5083 | C-CERAMIC,CHIP |
| 2203-007271 | C5097,C5129,C7064 | C-CERAMIC,CHIP |
| 2203-007279 | C7012,C7147 | C-CERAMIC,CHIP |
| 2203-007317 | C7014 | C-CERAMIC,CHIP |
| 2203-007391 | C2031,C5133,C5136 | C-CERAMIC,CHIP |
| 2203-007392 | C5061,C5098 | C-CERAMIC,CHIP |
| 2203-007393 | C1105,C2012,C3011 | C-CERAMIC,CHIP |
| 2203-007393 | C3100,C3101,C4011 | C-CERAMIC,CHIP |
| 2203-007393 | C4023,C4024,C4039 | C-CERAMIC,CHIP |
| 2203-007393 | C4074,C4078,C5032 | C-CERAMIC,CHIP |
| 2203-007393 | C5066,C5084,C5087 | C-CERAMIC,CHIP |
| 2203-007393 | C5096,C5118,C5124 | C-CERAMIC,CHIP |
| 2203-007393 | C5127,C5168,C5169 | C-CERAMIC,CHIP |
| 2203-007393 | C5170,C5171,C6025 | C-CERAMIC,CHIP |
| 2203-007393 | C7003,C7018,C7023 | C-CERAMIC,CHIP |
| 2203-007393 | C7024,C7027,C7028 | C-CERAMIC,CHIP |
| 2203-007393 | C7133 | C-CERAMIC,CHIP |
| 2203-007456 | C5086,C6032 | C-CERAMIC,CHIP |
| 2203-007474 | C2017,C2021,C2023 | C-CERAMIC,CHIP |
| 2203-007474 | C2027,C2034,C4047 | C-CERAMIC,CHIP |
| 2203-007474 | C4049,C4069,C5056 | C-CERAMIC,CHIP |
| 2203-007796 | C2011,C2019,C2025 | C-CERAMIC,CHIP |
| 2203-007796 | C2049,C3000,C3008 | C-CERAMIC,CHIP |
| 2203-007796 | C3013,C3018,C3094 | C-CERAMIC,CHIP |
| 2203-007796 | C3096,C3097,C3102 | C-CERAMIC,CHIP |
| 2203-007796 | C4002,C4004,C4006 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-007796 | C4007,C4008,C4009 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-007796 | C4014,C4015,C4018 | C-CERAMIC,CHIP |
| 2203-007796 | C4019,C4020,C4021 | C-CERAMIC,CHIP |
| 2203-007796 | C4022,C4029,C4030 | C-CERAMIC,CHIP |
| 2203-007796 | C4033,C4034,C4037 | C-CERAMIC,CHIP |
| 2203-007796 | C4038,C4044,C4045 | C-CERAMIC,CHIP |
| 2203-007796 | C4052,C4053,C4055 | C-CERAMIC,CHIP |
| 2203-007796 | C4056,C4063,C4065 | C-CERAMIC,CHIP |
| 2203-007796 | C4066,C4067,C4070 | C-CERAMIC,CHIP |
| 2203-007796 | C4071,C4072,C4073 | C-CERAMIC,CHIP |
| 2203-007796 | C4075,C4076,C4077 | C-CERAMIC,CHIP |
| 2203-007796 | C4079,C4080,C4081 | C-CERAMIC,CHIP |
| 2203-007796 | C4082,C4083,C4088 | C-CERAMIC,CHIP |
| 2203-007796 | C4089,C4090,C4091 | C-CERAMIC,CHIP |
| 2203-007796 | C4092,C4093,C4094 | C-CERAMIC,CHIP |
| 2203-007796 | C4259,C5008,C5009 | C-CERAMIC,CHIP |
| 2203-007796 | C5012,C5014,C5015 | C-CERAMIC,CHIP |
| 2203-007796 | C5016,C5017,C5018 | C-CERAMIC,CHIP |
| 2203-007796 | C5019,C5020,C5024 | C-CERAMIC,CHIP |
| 2203-007796 | C5025,C5026,C5030 | C-CERAMIC,CHIP |
| 2203-007796 | C5073,C5085,C5093 | C-CERAMIC,CHIP |
| 2203-007796 | C5101,C5102,C5104 | C-CERAMIC,CHIP |
| 2203-007796 | C5107,C5108,C5110 | C-CERAMIC,CHIP |
| 2203-007796 | C5128,C5166,C7005 | C-CERAMIC,CHIP |
| 2203-007796 | C7013,C7015,C7025 | C-CERAMIC,CHIP |
| 2203-007796 | C7026,C7033,C7041 | C-CERAMIC,CHIP |
| 2203-007796 | C7065,C7066,C7068 | C-CERAMIC,CHIP |
| 2203-007796 | C7144,C7145 | C-CERAMIC,CHIP |
| 2203-008097 | C6054 | C-CERAMIC,CHIP |
| 2203-008158 | C5079 | C-CERAMIC,CHIP |
| 2203-008242 | C2058,C3005,C3016 | C-CERAMIC,CHIP |
| 2203-008242 | C4001,C4003,C4017 | C-CERAMIC,CHIP |
| 2203-008242 | C4043,C5000,C5002 | C-CERAMIC,CHIP |
| 2203-008242 | C5004,C5007,C5011 | C-CERAMIC,CHIP |
| 2203-008242 | C5021,C5022,C5023 | C-CERAMIC,CHIP |
| 2203-008242 | C5027,C5036,C6053 | C-CERAMIC,CHIP |
| 2203-008242 | C7031,C7152 | C-CERAMIC,CHIP |
| 2203-008654 | C6031 | C-CERAMIC,CHIP |
| 2203-008860 | C2057,C3092,C3093 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-008860 | C3095,C5100,C5121 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-008860 | C5134,C6056,C7032 | C-CERAMIC,CHIP |
| 2203-008860 | C7040,C7042,C7067 | C-CERAMIC,CHIP |
| 2203-008860 | C7069,C7070 | C-CERAMIC,CHIP |
| 2203-008876 | C1069,C1098,C3010 | C-CERAMIC,CHIP |
| 2203-008876 | C5075,C5119,C6057 | C-CERAMIC,CHIP |
| 2203-008876 | C7029,C7030,C7188 | C-CERAMIC,CHIP |
| 2203-009328 | C4060,C4061,C4086 | C-CERAMIC,CHIP |
| 2203-009328 | C5039,C5041,C5042 | C-CERAMIC,CHIP |
| 2203-009328 | C5047,C5052,C5060 | C-CERAMIC,CHIP |
| 2203-009328 | C5063,C5074 | C-CERAMIC,CHIP |
| 2203-009537 | C5003 | C-CERAMIC,CHIP |
| 2203-009618 | C5069,C5077,C6006 | C-CERAMIC,CHIP |
| 2203-009618 | C6055,C7044 | C-CERAMIC,CHIP |
| 2203-009733 | C1075,C2009,C5035 | C-CERAMIC,CHIP |
| 2203-009733 | C5037,C5040,C5043 | C-CERAMIC,CHIP |
| 2203-009733 | C5048,C5050,C5051 | C-CERAMIC,CHIP |
| 2203-009733 | C5054,C5055,C5065 | C-CERAMIC,CHIP |
| 2203-009733 | C5071,C5072,C5076 | C-CERAMIC,CHIP |
| 2203-009733 | C5081,C5091,C5152 | C-CERAMIC,CHIP |
| 2203-009733 | C6052,C7045,C7046 | C-CERAMIC,CHIP |
| 2203-009733 | C7047,C7048,C7049 | C-CERAMIC,CHIP |
| 2203-009733 | C7050,C7051,C7054 | C-CERAMIC,CHIP |
| 2203-009733 | C7055,C7056,C7060 | C-CERAMIC,CHIP |
| 2203-009733 | C7061,C7062,C7148 | C-CERAMIC,CHIP |
| 2203-009733 | C7150,C7151 | C-CERAMIC,CHIP |
| 2203-010085 | C5044 | C-CERAMIC,CHIP |
| 2703-002649 | L1033,L1040,L1049 | INDUCTOR-SMD |
| 2703-002649 | L2029 | INDUCTOR-SMD |
| 2703-002900 | C1079 | INDUCTOR-SMD |
| 2703-002903 | L3013,L6010,L6011 | INDUCTOR-SMD |
| 2703-002907 | C1096,L2031 | INDUCTOR-SMD |
| 2703-002955 | L2020 | INDUCTOR-SMD |
| 2703-002959 | L2028,L3011 | INDUCTOR-SMD |
| 2703-002999 | C1112,L1005,L3027 | INDUCTOR-SMD |
| 2703-003476 | L3000 | INDUCTOR-SMD |
| 2703-003970 | L1046,L1051,L3014 | INDUCTOR-SMD |
| 2703-004012 | L1035,L1054,L1061 | INDUCTOR-SMD |
| 2703-004012 | L2024 | INDUCTOR-SMD |

5. MAIN Electrical Parts List

| 2703-004013 | L1028,L3015 | INDUCTOR-SMD |
|-------------|-------------------|--------------|
| 2703-004014 | L2022,L2023,L3010 | INDUCTOR-SMD |
| 2703-004018 | C1057,C1073,C1115 | INDUCTOR-SMD |
| 2703-004018 | C1127,L1007,L1055 | INDUCTOR-SMD |
| 2703-004018 | L1060 | INDUCTOR-SMD |
| 2703-004032 | C1092,L1032,L1045 | INDUCTOR-SMD |
| 2703-004034 | C1051,C2046,L1025 | INDUCTOR-SMD |
| 2703-004034 | L1029,L3002 | INDUCTOR-SMD |
| 2703-004035 | L2001,L2004,L2038 | INDUCTOR-SMD |
| 2703-004036 | C1129,L1011,L3004 | INDUCTOR-SMD |
| 2703-004037 | L2000,L2003,L2035 | INDUCTOR-SMD |
| 2703-004038 | C1063,C3040,L1023 | INDUCTOR-SMD |
| 2703-004038 | L1042,L1057,L2010 | INDUCTOR-SMD |
| 2703-004171 | L1016 | INDUCTOR-SMD |
| 2703-004193 | L1003 | INDUCTOR-SMD |
| 2703-004286 | C1059,C3038,L1010 | INDUCTOR-SMD |
| 2703-004286 | L1062 | INDUCTOR-SMD |
| 2703-004300 | L1047 | INDUCTOR-SMD |
| 2703-004301 | C1058 | INDUCTOR-SMD |
| 2703-004317 | L1013,L3001 | INDUCTOR-SMD |
| 2703-004328 | L1004,L1031,L1052 | INDUCTOR-SMD |
| 2703-004328 | L2002,L2007 | INDUCTOR-SMD |
| 2703-004363 | L2030 | INDUCTOR-SMD |
| 2703-004367 | C1134,L3016 | INDUCTOR-SMD |
| 2703-004368 | L3003,U1008 | INDUCTOR-SMD |
| 2703-004408 | L1015,L1017,L1021 | INDUCTOR-SMD |
| 2703-004408 | L1056 | INDUCTOR-SMD |
| 2703-004763 | C1137,C1140,L1001 | INDUCTOR-SMD |
| 2703-004763 | L1002,L1053 | INDUCTOR-SMD |
| 2703-004764 | L2015,L2034 | INDUCTOR-SMD |
| 2703-004862 | L1034 | INDUCTOR-SMD |
| 2703-005066 | L2008 | INDUCTOR-SMD |
| 2703-005085 | L1063 | INDUCTOR-SMD |
| 2703-005087 | L1030,L1037,L1050 | INDUCTOR-SMD |
| 2703-005200 | L6012 | INDUCTOR-SMD |
| 2703-005201 | L5001,L5003,L5004 | INDUCTOR-SMD |
| 2703-005201 | L5005,L5011 | INDUCTOR-SMD |
| 2703-005224 | L7009 | INDUCTOR-SMD |
| 2703-005296 | L1041,L1065 | INDUCTOR-SMD |

5. MAIN Electrical Parts List

| 2703-005366 | C1124 | INDUCTOR-SMD |
|-------------|-------------------|-------------------|
| 2703-005418 | L7006 | INDUCTOR-SMD |
| 2703-005419 | L7007 | INDUCTOR-SMD |
| 2703-005689 | L5002,L5006,L5007 | INDUCTOR-SMD |
| 2703-005689 | L5009,L5012 | INDUCTOR-SMD |
| 2801-005389 | OSC5000 | CRYSTAL-UNIT |
| 2805-001117 | OSC2000 | OSCILLATOR |
| 2901-001690 | C4057,C4058,C4059 | FILTER-EMI SMD |
| 2901-001690 | C4084,C4085,U4009 | FILTER-EMI SMD |
| 2901-001690 | U4010 | FILTER-EMI SMD |
| 2904-002198 | F2002 | FILTER-SAW |
| 2904-002210 | F1005 | FILTER-SAW |
| 2904-002326 | F2003 | FILTER-SAW |
| 2904-002339 | F2000 | FILTER-SAW |
| 2904-002350 | F1008 | FILTER-SAW |
| 2904-002355 | F3002,F3003 | FILTER-SAW |
| 2904-002381 | F3000 | FILTER-SAW |
| 2904-002397 | F1006,F2001 | FILTER-SAW |
| 2910-000364 | F1007 | FILTER |
| 2910-000367 | F1010 | FILTER |
| 2910-000402 | F1009 | FILTER |
| 2911-000430 | U2000 | FILTER |
| 2911-000450 | U1007 | FILTER |
| 3003-001237 | MIC6000 | MIC-CONDENSOR |
| 3301-002078 | R6011 | CORE-FERRITE BEAD |
| 3301-002122 | L2005,L2006,L6008 | CORE-FERRITE BEAD |
| 3301-002122 | L6018 | CORE-FERRITE BEAD |
| 3301-002223 | L7000,L7001,L7002 | CORE-FERRITE BEAD |
| 3301-002223 | L7004 | CORE-FERRITE BEAD |
| 3301-002235 | L6001,L6003,L6004 | CORE-FERRITE BEAD |
| 3301-002235 | L6005,L6006,L6007 | CORE-FERRITE BEAD |
| 3301-002235 | L6009,L6013 | CORE-FERRITE BEAD |
| 3301-002237 | L1000,L2027,L2037 | CORE-FERRITE BEAD |
| 3301-002238 | L2013,L2017,L2019 | CORE-FERRITE BEAD |
| 3301-002238 | L3012,L6000,L6002 | CORE-FERRITE BEAD |
| 3301-002239 | L2011 | CORE-FERRITE BEAD |
| 3301-002242 | L2036 | CORE-FERRITE BEAD |
| 3301-002312 | L2014,L2016,L2018 | CORE-FERRITE BEAD |
| 3301-002312 | L7005,L7008,L7010 | CORE-FERRITE BEAD |

5. MAIN Electrical Parts List

| 3301-002331 | L5008 | CORE-FERRITE BEAD |
|-------------|-----------------|---------------------|
| 3705-001937 | RFS1000,RFS1001 | CONNECTOR-COAXIAL |
| 3709-001932 | SIM4UP | CONNECTOR-CARD EDGE |
| 3709-001933 | SIM3 | CONNECTOR-CARD EDGE |
| 3709-001934 | SIM1,SIM2 | CONNECTOR-CARD EDGE |
| 3710-003193 | SOC7000 | CONNECTOR-SOCKET |
| 3710-003985 | SOC6000 | CONNECTOR-SOCKET |
| 3711-007107 | HDC7002 | CONNECTOR-HEADER |
| 3711-007295 | HDC7001 | CONNECTOR-HEADER |
| 3711-008511 | HDC7003 | CONNECTOR-HEADER |
| 3711-008847 | BTC5000 | CONNECTOR-HEADER |
| 3711-008997 | HEA5000 | CONNECTOR-HEADER |
| 3712-001621 | ANT2000,ANT2001 | CONNECTOR |
| 3712-001621 | ANT2002,ANT2003 | CONNECTOR |
| 3712-001621 | ANT2004,ANT2008 | CONNECTOR |
| 3712-001621 | ANT5000,ANT5001 | CONNECTOR |
| 3712-001621 | ANT5003,ANT5004 | CONNECTOR |
| 3712-001621 | ANT5006 | CONNECTOR |
| 3712-001626 | ANT2006,ANT2009 | CONNECTOR |
| 3712-001633 | ANT5002,ANT5005 | CONNECTOR |
| 3712-001666 | ANT6000,ANT6001 | CONNECTOR |
| 3712-001714 | ANT3000,ANT3002 | CONNECTOR |
| 4709-002196 | F2004 | RF-MODULE |
| 4709-002412 | F1000,F1001 | RF-MODULE |
| GH02-18335A | SC6005SP | EMI SHEET |
| GH61-08634A | CON1000 | C-CLIP |
| GH62-00042A | GA7000 | GASKET |
| GH63-16268A | SC6000 | SHIELDCAN |
| GH63-16890A | SC6002 | SHIELDCAN |
| GH63-16937A | SC6003 | SHIELDCAN |
| GH63-16938A | SC6004 | SHIELDCAN |
| GH98-44134A | SC6005 | SHIELDCAN |

5. MAIN Electrical Parts List

[SM-A205GN]

| Parts Code | Design LOC | Description |
|-------------|----------------------|-----------------|
| 0401-001110 | D5001 | DIODE-SWITCHING |
| 0404-001250 | D5000 | DIODE-SCHOTTKY |
| 0406-001506 | ZD1001,ZD1002 | DIODE-TVS |
| 0406-001561 | ZD5002,ZD5011,ZD6000 | DIODE-TVS |
| 0406-001561 | ZD6001,ZD6026 | DIODE-TVS |
| 0406-001592 | ZD5004,ZD6021 | DIODE-TVS |
| 0406-001728 | ZD5001 | DIODE-TVS |
| 0406-001781 | ZD6024,ZD6025 | DIODE-TVS |
| 0406-001809 | ZD6015,ZD6016 | DIODE-TVS |
| 0406-001837 | D6000 | DIODE-TVS |
| 0505-003618 | Q5000 | FET-SILICON |
| 0601-003768 | LED5000 | LED |
| 1001-001974 | U1003 | IC |
| 1001-001975 | U1009,U2002,U2006 | IC |
| 1001-001975 | U2007 | IC |
| 1001-002078 | U2003 | IC |
| 1003-002802 | U2004 | IC |
| 1105-002962 | UCP400UP | RAM(POP) |
| 1107-002552 | UME5000 | IC |
| 1201-003869 | U3005 | IC |
| 1201-003984 | U1002,U1005 | IC |
| 1201-004100 | U1006 | IC |
| 1201-004209 | PAM1000 | IC |
| 1201-004228 | U6001 | IC |
| 1203-008249 | U3011 | IC |
| 1203-008475 | U6002 | IC |
| 1203-008603 | U5007 | IC |
| 1203-008693 | U2001 | IC |
| 1203-008771 | U3015 | IC |
| 1203-008867 | U3000,U7003 | IC |
| 1203-008872 | U7002,U7004 | IC |
| 1203-008925 | U3013 | IC |
| 1203-008989 | U7000 | IC |
| 1203-009211 | U5002 | IC |
| 1203-009213 | U5001 | IC |
| 1203-009220 | U7001 | IC |
| 1203-009221 | U7005 | IC |

5. MAIN Electrical Parts List

| 1205-005806 | U2012 | IC |
|-------------|----------------------|------------|
| 1205-005860 | U3003 | IC |
| 1205-006088 | U3004 | IC |
| 1205-006117 | UCP400 | IC |
| 1209-002413 | U3014 | IC |
| 1209-002450 | U3012 | IC |
| 1209-002629 | U3016 | IC |
| 1404-001724 | TH1000,TH4000,VR5000 | THERMISTOR |
| 1405-001429 | V7000 | VARISTOR |
| 2007-000141 | R3005,R3012,R3014 | R-CHIP |
| 2007-003015 | R6062,R6063 | R-CHIP |
| 2007-007190 | R6064,R6067 | R-CHIP |
| 2007-007310 | R3001,R3002 | R-CHIP |
| 2007-007741 | R4012,R5025,R5027 | R-CHIP |
| 2007-007741 | R6061 | R-CHIP |
| 2007-007798 | R6025 | R-CHIP |
| 2007-007942 | R5000 | R-CHIP |
| 2007-007946 | R5004 | R-CHIP |
| 2007-008052 | R5022,R5024,R7001 | R-CHIP |
| 2007-008052 | R7009 | R-CHIP |
| 2007-008055 | R4001,R4010,R4047 | R-CHIP |
| 2007-008419 | R4041,R5023 | R-CHIP |
| 2007-008483 | R5020,R5021 | R-CHIP |
| 2007-008516 | R3003,R4015,R4016 | R-CHIP |
| 2007-008516 | R4027,R4226,R6003 | R-CHIP |
| 2007-008516 | R6023,R6024 | R-CHIP |
| 2007-008531 | R5015,R6009,R7000 | R-CHIP |
| 2007-008531 | R7004,R7014 | R-CHIP |
| 2007-008588 | R3006,R3007,R4017 | R-CHIP |
| 2007-008588 | R4018,R4022,R4023 | R-CHIP |
| 2007-008588 | R4024,R4026,R4030 | R-CHIP |
| 2007-008588 | R4032,R4034,R4036 | R-CHIP |
| 2007-008588 | R4037,R4228,R4231 | R-CHIP |
| 2007-008588 | R4334,R4335,R4336 | R-CHIP |
| 2007-008800 | R6012 | R-CHIP |
| 2007-008806 | R2001 | R-CHIP |
| 2007-009084 | R6000 | R-CHIP |
| 2007-009111 | R3004,R5029 | R-CHIP |
| 2007-009157 | R1007,R4002,R4003 | R-CHIP |

5. MAIN Electrical Parts List

| 2007-009157 | R5009,R5105,R6026 | R-CHIP |
|-------------|-------------------|----------------|
| 2007-009171 | R5003,R5008 | R-CHIP |
| 2007-009212 | R5011,R6006 | R-CHIP |
| 2007-009352 | R5019 | R-CHIP |
| 2007-009361 | R1000,R1002 | R-CHIP |
| 2007-009408 | R6007 | R-CHIP |
| 2007-009410 | R6038,R6039 | R-CHIP |
| 2007-009766 | R3000 | R-CHIP |
| 2007-009793 | R6014 | R-CHIP |
| 2007-009801 | R5007 | R-CHIP |
| 2007-009805 | R1001,R1003,R1004 | R-CHIP |
| 2007-009920 | R4004,R4005,R4007 | R-CHIP |
| 2007-009920 | R4009 | R-CHIP |
| 2007-009969 | R6008 | R-CHIP |
| 2007-010685 | R7003 | R-CHIP |
| 2007-011043 | R4200,R4201,R4202 | R-CHIP |
| 2007-011043 | R4203,R4333 | R-CHIP |
| 2007-011532 | R6010 | R-CHIP |
| 2007-011648 | R6019 | R-CHIP |
| 2007-012068 | R5002 | R-CHIP |
| 2203-000330 | C3050 | C-CERAMIC,CHIP |
| 2203-000489 | C5173,C5174 | C-CERAMIC,CHIP |
| 2203-001153 | C3044,C3052 | C-CERAMIC,CHIP |
| 2203-001239 | C3049 | C-CERAMIC,CHIP |
| 2203-005344 | C5267 | C-CERAMIC,CHIP |
| 2203-005682 | C5117,C5123,C5556 | C-CERAMIC,CHIP |
| 2203-005725 | C1133,C7006,L1038 | C-CERAMIC,CHIP |
| 2203-005727 | C1123,C1132 | C-CERAMIC,CHIP |
| 2203-005729 | C6000,C6004,C6010 | C-CERAMIC,CHIP |
| 2203-005729 | C6015,C6018,C6019 | C-CERAMIC,CHIP |
| 2203-005729 | C7011 | C-CERAMIC,CHIP |
| 2203-005731 | C1125,C2055,C6058 | C-CERAMIC,CHIP |
| 2203-005731 | C6059 | C-CERAMIC,CHIP |
| 2203-005732 | C5049,C6009,C6016 | C-CERAMIC,CHIP |
| 2203-005732 | C6017,C6022 | C-CERAMIC,CHIP |
| 2203-005734 | C3057 | C-CERAMIC,CHIP |
| 2203-005736 | C1000,C1003,C1006 | C-CERAMIC,CHIP |
| 2203-005736 | C1017,C1018,C1022 | C-CERAMIC,CHIP |
| 2203-005736 | C1028,C1034,C1040 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-005736 | C1052,C1053,C1060 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-005736 | C1072,C1083,C1084 | C-CERAMIC,CHIP |
| 2203-005736 | C1085,C1091,C1114 | C-CERAMIC,CHIP |
| 2203-005736 | C1141,C2002,C2004 | C-CERAMIC,CHIP |
| 2203-005736 | C2006,C2014,C2030 | C-CERAMIC,CHIP |
| 2203-005736 | C2036,C2041,C2047 | C-CERAMIC,CHIP |
| 2203-005736 | C2050,C3003,C3007 | C-CERAMIC,CHIP |
| 2203-005736 | C3014,C3028,C3029 | C-CERAMIC,CHIP |
| 2203-005736 | C3054,C3061,L1008 | C-CERAMIC,CHIP |
| 2203-005736 | L1044 | C-CERAMIC,CHIP |
| 2203-005740 | C3036 | C-CERAMIC,CHIP |
| 2203-005777 | C1086,C1089,C1093 | C-CERAMIC,CHIP |
| 2203-005777 | C1113 | C-CERAMIC,CHIP |
| 2203-005789 | C1025,C1103,C1116 | C-CERAMIC,CHIP |
| 2203-005789 | C1117,C1118,C1119 | C-CERAMIC,CHIP |
| 2203-005789 | C1120,C1126,C1142 | C-CERAMIC,CHIP |
| 2203-005789 | L1026 | C-CERAMIC,CHIP |
| 2203-005792 | C1078,C1095,C1110 | C-CERAMIC,CHIP |
| 2203-005792 | C1122,C1139,C2003 | C-CERAMIC,CHIP |
| 2203-005806 | C1099,C1106,C1108 | C-CERAMIC,CHIP |
| 2203-005806 | C2000,C3030 | C-CERAMIC,CHIP |
| 2203-006121 | C6014 | C-CERAMIC,CHIP |
| 2203-006187 | C6029 | C-CERAMIC,CHIP |
| 2203-006194 | C6008 | C-CERAMIC,CHIP |
| 2203-006305 | C1107,L2009 | C-CERAMIC,CHIP |
| 2203-006318 | C1077,C1088,L1064 | C-CERAMIC,CHIP |
| 2203-006318 | L2032 | C-CERAMIC,CHIP |
| 2203-006379 | C6060 | C-CERAMIC,CHIP |
| 2203-006400 | C1002,C1011,C2048 | C-CERAMIC,CHIP |
| 2203-006400 | C3039,C3043,C3053 | C-CERAMIC,CHIP |
| 2203-006400 | C4013,C6051 | C-CERAMIC,CHIP |
| 2203-006410 | C1087 | C-CERAMIC,CHIP |
| 2203-006423 | C2032,C3066,C3098 | C-CERAMIC,CHIP |
| 2203-006423 | C3099,C4005,C5120 | C-CERAMIC,CHIP |
| 2203-006423 | C5172,C5555,C6013 | C-CERAMIC,CHIP |
| 2203-006423 | C6026,C6028,C7034 | C-CERAMIC,CHIP |
| 2203-006556 | C1036,C3058,C5045 | C-CERAMIC,CHIP |
| 2203-006604 | C1104,C3062,C6030 | C-CERAMIC,CHIP |
| 2203-006611 | C1081,C1109 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-006648 | C6021 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-006665 | L1059 | C-CERAMIC,CHIP |
| 2203-006668 | C4064 | C-CERAMIC,CHIP |
| 2203-006674 | C2042,C3027 | C-CERAMIC,CHIP |
| 2203-006707 | C1008 | C-CERAMIC,CHIP |
| 2203-006839 | C1012,C1048,C1068 | C-CERAMIC,CHIP |
| 2203-006839 | C1071,C1074,C1131 | C-CERAMIC,CHIP |
| 2203-006839 | C1136,C2001,C4035 | C-CERAMIC,CHIP |
| 2203-006839 | C5092,C5095 | C-CERAMIC,CHIP |
| 2203-006846 | C1111,C4204,C4205 | C-CERAMIC,CHIP |
| 2203-006846 | C4206,C4207 | C-CERAMIC,CHIP |
| 2203-006979 | C2010,C2018,C2020 | C-CERAMIC,CHIP |
| 2203-006979 | C2022,C2024,C2026 | C-CERAMIC,CHIP |
| 2203-006979 | C2028,C2033,C2054 | C-CERAMIC,CHIP |
| 2203-007194 | C1014,C3059,C3067 | C-CERAMIC,CHIP |
| 2203-007194 | C7007 | C-CERAMIC,CHIP |
| 2203-007210 | C4050,C4051,C4068 | C-CERAMIC,CHIP |
| 2203-007210 | C4087,C5125,C5126 | C-CERAMIC,CHIP |
| 2203-007235 | C5038,C5058 | C-CERAMIC,CHIP |
| 2203-007271 | C2053,C4062,C5083 | C-CERAMIC,CHIP |
| 2203-007271 | C5097,C5129,C7064 | C-CERAMIC,CHIP |
| 2203-007279 | C7012,C7147 | C-CERAMIC,CHIP |
| 2203-007317 | C3020,C3021,C7014 | C-CERAMIC,CHIP |
| 2203-007391 | C2031,C5133,C5136 | C-CERAMIC,CHIP |
| 2203-007392 | C5061,C5098 | C-CERAMIC,CHIP |
| 2203-007393 | C1105,C2012,C3011 | C-CERAMIC,CHIP |
| 2203-007393 | C3100,C3101,C4011 | C-CERAMIC,CHIP |
| 2203-007393 | C4023,C4024,C4039 | C-CERAMIC,CHIP |
| 2203-007393 | C4074,C4078,C5032 | C-CERAMIC,CHIP |
| 2203-007393 | C5066,C5084,C5087 | C-CERAMIC,CHIP |
| 2203-007393 | C5096,C5118,C5124 | C-CERAMIC,CHIP |
| 2203-007393 | C5127,C5168,C5169 | C-CERAMIC,CHIP |
| 2203-007393 | C5170,C5171,C6025 | C-CERAMIC,CHIP |
| 2203-007393 | C7003,C7018,C7023 | C-CERAMIC,CHIP |
| 2203-007393 | C7024,C7027,C7028 | C-CERAMIC,CHIP |
| 2203-007393 | C7133 | C-CERAMIC,CHIP |
| 2203-007456 | C5086,C6032 | C-CERAMIC,CHIP |
| 2203-007474 | C2017,C2021,C2023 | C-CERAMIC,CHIP |
| 2203-007474 | C2027,C2034,C4047 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-007474 | C4049,C4069,C5056 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-007796 | C2011,C2019,C2025 | C-CERAMIC,CHIP |
| 2203-007796 | C2049,C3000,C3002 | C-CERAMIC,CHIP |
| 2203-007796 | C3008,C3013,C3018 | C-CERAMIC,CHIP |
| 2203-007796 | C3022,C3031,C3094 | C-CERAMIC,CHIP |
| 2203-007796 | C3096,C3097,C3102 | C-CERAMIC,CHIP |
| 2203-007796 | C4002,C4004,C4006 | C-CERAMIC,CHIP |
| 2203-007796 | C4007,C4008,C4009 | C-CERAMIC,CHIP |
| 2203-007796 | C4014,C4015,C4018 | C-CERAMIC,CHIP |
| 2203-007796 | C4019,C4020,C4021 | C-CERAMIC,CHIP |
| 2203-007796 | C4022,C4029,C4030 | C-CERAMIC,CHIP |
| 2203-007796 | C4033,C4034,C4037 | C-CERAMIC,CHIP |
| 2203-007796 | C4038,C4044,C4045 | C-CERAMIC,CHIP |
| 2203-007796 | C4052,C4053,C4055 | C-CERAMIC,CHIP |
| 2203-007796 | C4056,C4063,C4065 | C-CERAMIC,CHIP |
| 2203-007796 | C4066,C4067,C4070 | C-CERAMIC,CHIP |
| 2203-007796 | C4071,C4072,C4073 | C-CERAMIC,CHIP |
| 2203-007796 | C4075,C4076,C4077 | C-CERAMIC,CHIP |
| 2203-007796 | C4079,C4080,C4081 | C-CERAMIC,CHIP |
| 2203-007796 | C4082,C4083,C4088 | C-CERAMIC,CHIP |
| 2203-007796 | C4089,C4090,C4091 | C-CERAMIC,CHIP |
| 2203-007796 | C4092,C4093,C4094 | C-CERAMIC,CHIP |
| 2203-007796 | C4259,C5008,C5009 | C-CERAMIC,CHIP |
| 2203-007796 | C5012,C5014,C5015 | C-CERAMIC,CHIP |
| 2203-007796 | C5016,C5017,C5018 | C-CERAMIC,CHIP |
| 2203-007796 | C5019,C5020,C5024 | C-CERAMIC,CHIP |
| 2203-007796 | C5025,C5026,C5030 | C-CERAMIC,CHIP |
| 2203-007796 | C5073,C5085,C5093 | C-CERAMIC,CHIP |
| 2203-007796 | C5101,C5102,C5104 | C-CERAMIC,CHIP |
| 2203-007796 | C5107,C5108,C5110 | C-CERAMIC,CHIP |
| 2203-007796 | C5128,C5166,C7005 | C-CERAMIC,CHIP |
| 2203-007796 | C7013,C7015,C7025 | C-CERAMIC,CHIP |
| 2203-007796 | C7026,C7033,C7041 | C-CERAMIC,CHIP |
| 2203-007796 | C7065,C7066,C7068 | C-CERAMIC,CHIP |
| 2203-007796 | C7144,C7145 | C-CERAMIC,CHIP |
| 2203-008097 | C6054 | C-CERAMIC,CHIP |
| 2203-008158 | C5079 | C-CERAMIC,CHIP |
| 2203-008242 | C2058,C3005,C3016 | C-CERAMIC,CHIP |
| 2203-008242 | C4001,C4003,C4017 | C-CERAMIC,CHIP |

5. MAIN Electrical Parts List

| 2203-008242 | C4043,C5000,C5002 | C-CERAMIC,CHIP |
|-------------|-------------------|----------------|
| 2203-008242 | C5004,C5007,C5011 | C-CERAMIC,CHIP |
| 2203-008242 | C5021,C5022,C5023 | C-CERAMIC,CHIP |
| 2203-008242 | C5027,C5036,C6053 | C-CERAMIC,CHIP |
| 2203-008242 | C7031,C7152 | C-CERAMIC,CHIP |
| 2203-008654 | C6031 | C-CERAMIC,CHIP |
| 2203-008860 | C2057,C3006,C3092 | C-CERAMIC,CHIP |
| 2203-008860 | C3093,C3095,C5100 | C-CERAMIC,CHIP |
| 2203-008860 | C5121,C5134,C6056 | C-CERAMIC,CHIP |
| 2203-008860 | C7032,C7040,C7042 | C-CERAMIC,CHIP |
| 2203-008860 | C7067,C7069,C7070 | C-CERAMIC,CHIP |
| 2203-008876 | C1069,C1098,C3010 | C-CERAMIC,CHIP |
| 2203-008876 | C5075,C5119,C6057 | C-CERAMIC,CHIP |
| 2203-008876 | C7029,C7030,C7188 | C-CERAMIC,CHIP |
| 2203-009167 | C3048,C3051 | C-CERAMIC,CHIP |
| 2203-009328 | C4060,C4061,C4086 | C-CERAMIC,CHIP |
| 2203-009328 | C5039,C5041,C5042 | C-CERAMIC,CHIP |
| 2203-009328 | C5047,C5052,C5060 | C-CERAMIC,CHIP |
| 2203-009328 | C5063,C5074 | C-CERAMIC,CHIP |
| 2203-009537 | C5003 | C-CERAMIC,CHIP |
| 2203-009618 | C5069,C5077,C6006 | C-CERAMIC,CHIP |
| 2203-009618 | C6055,C7044 | C-CERAMIC,CHIP |
| 2203-009733 | C1075,C2009,C3025 | C-CERAMIC,CHIP |
| 2203-009733 | C3026,C3035,C5035 | C-CERAMIC,CHIP |
| 2203-009733 | C5037,C5040,C5043 | C-CERAMIC,CHIP |
| 2203-009733 | C5048,C5050,C5051 | C-CERAMIC,CHIP |
| 2203-009733 | C5054,C5055,C5065 | C-CERAMIC,CHIP |
| 2203-009733 | C5071,C5072,C5076 | C-CERAMIC,CHIP |
| 2203-009733 | C5081,C5091,C5152 | C-CERAMIC,CHIP |
| 2203-009733 | C6052,C7045,C7046 | C-CERAMIC,CHIP |
| 2203-009733 | C7047,C7048,C7049 | C-CERAMIC,CHIP |
| 2203-009733 | C7050,C7051,C7054 | C-CERAMIC,CHIP |
| 2203-009733 | C7055,C7056,C7060 | C-CERAMIC,CHIP |
| 2203-009733 | C7061,C7062,C7148 | C-CERAMIC,CHIP |
| 2203-009733 | C7150,C7151 | C-CERAMIC,CHIP |
| 2203-010085 | C5044 | C-CERAMIC,CHIP |
| 2703-002649 | L1033,L1040,L1049 | INDUCTOR-SMD |
| 2703-002649 | L2029 | INDUCTOR-SMD |
| 2703-002900 | C1079 | INDUCTOR-SMD |

5. MAIN Electrical Parts List

| 2703-002903 | L3013,L6010,L6011 | INDUCTOR-SMD |
|-------------|-------------------|--------------|
| 2703-002907 | C1096,L2031 | INDUCTOR-SMD |
| 2703-002955 | L2020 | INDUCTOR-SMD |
| 2703-002959 | L2028,L3011 | INDUCTOR-SMD |
| 2703-002999 | C1112,L1005,L3027 | INDUCTOR-SMD |
| 2703-003476 | L3000 | INDUCTOR-SMD |
| 2703-003970 | L1046,L1051,L3014 | INDUCTOR-SMD |
| 2703-004012 | L1035,L1054,L1061 | INDUCTOR-SMD |
| 2703-004012 | L2024 | INDUCTOR-SMD |
| 2703-004013 | L1028,L3015 | INDUCTOR-SMD |
| 2703-004014 | L2022,L2023,L3010 | INDUCTOR-SMD |
| 2703-004018 | C1057,C1073,C1115 | INDUCTOR-SMD |
| 2703-004018 | C1127,L1007,L1055 | INDUCTOR-SMD |
| 2703-004018 | L1060 | INDUCTOR-SMD |
| 2703-004032 | C1092,L1032,L1045 | INDUCTOR-SMD |
| 2703-004034 | C1051,C2046,L1025 | INDUCTOR-SMD |
| 2703-004034 | L1029,L3002 | INDUCTOR-SMD |
| 2703-004035 | L2001,L2004,L2038 | INDUCTOR-SMD |
| 2703-004036 | C1129,L1011,L3004 | INDUCTOR-SMD |
| 2703-004037 | L2000,L2003,L2035 | INDUCTOR-SMD |
| 2703-004038 | C1063,C3040,L1023 | INDUCTOR-SMD |
| 2703-004038 | L1042,L1057,L2010 | INDUCTOR-SMD |
| 2703-004171 | L1016 | INDUCTOR-SMD |
| 2703-004193 | L1003 | INDUCTOR-SMD |
| 2703-004286 | C1059,C3038,L1010 | INDUCTOR-SMD |
| 2703-004286 | L1062 | INDUCTOR-SMD |
| 2703-004300 | L1047 | INDUCTOR-SMD |
| 2703-004301 | C1058 | INDUCTOR-SMD |
| 2703-004317 | L1013,L3001 | INDUCTOR-SMD |
| 2703-004328 | L1004,L1031,L1052 | INDUCTOR-SMD |
| 2703-004328 | L2002,L2007 | INDUCTOR-SMD |
| 2703-004363 | L2030 | INDUCTOR-SMD |
| 2703-004367 | C1134,L3016 | INDUCTOR-SMD |
| 2703-004368 | L3003,U1008 | INDUCTOR-SMD |
| 2703-004408 | L1015,L1017,L1021 | INDUCTOR-SMD |
| 2703-004408 | L1056 | INDUCTOR-SMD |
| 2703-004763 | C1137,C1140,L1001 | INDUCTOR-SMD |
| 2703-004763 | L1002,L1053 | INDUCTOR-SMD |
| 2703-004764 | L2015,L2034 | INDUCTOR-SMD |

5. MAIN Electrical Parts List

| 2703-004862 | L1034 | INDUCTOR-SMD |
|-------------|-------------------|-------------------|
| 2703-005066 | L2008 | INDUCTOR-SMD |
| 2703-005085 | L1063 | INDUCTOR-SMD |
| 2703-005087 | L1030,L1037,L1050 | INDUCTOR-SMD |
| 2703-005200 | L6012 | INDUCTOR-SMD |
| 2703-005201 | L5001,L5003,L5004 | INDUCTOR-SMD |
| 2703-005201 | L5005,L5011 | INDUCTOR-SMD |
| 2703-005224 | L7009 | INDUCTOR-SMD |
| 2703-005296 | L1041,L1065 | INDUCTOR-SMD |
| 2703-005366 | C1124 | INDUCTOR-SMD |
| 2703-005418 | L7006 | INDUCTOR-SMD |
| 2703-005419 | L7007 | INDUCTOR-SMD |
| 2703-005555 | L3008,L3009 | INDUCTOR-SMD |
| 2703-005689 | L5002,L5006,L5007 | INDUCTOR-SMD |
| 2703-005689 | L5009,L5012 | INDUCTOR-SMD |
| 2801-005389 | OSC5000 | CRYSTAL-UNIT |
| 2805-001117 | OSC2000 | OSCILLATOR |
| 2901-001690 | C4057,C4058,C4059 | FILTER-EMI SMD |
| 2901-001690 | C4084,C4085,U4009 | FILTER-EMI SMD |
| 2901-001690 | U4010 | FILTER-EMI SMD |
| 2904-002198 | F2002 | FILTER-SAW |
| 2904-002210 | F1005 | FILTER-SAW |
| 2904-002326 | F2003 | FILTER-SAW |
| 2904-002339 | F2000 | FILTER-SAW |
| 2904-002350 | F1008 | FILTER-SAW |
| 2904-002355 | F3002,F3003 | FILTER-SAW |
| 2904-002381 | F3000 | FILTER-SAW |
| 2904-002397 | F1006,F2001 | FILTER-SAW |
| 2910-000364 | F1007 | FILTER |
| 2910-000367 | F1010 | FILTER |
| 2910-000402 | F1009 | FILTER |
| 2911-000430 | U2000 | FILTER |
| 2911-000450 | U1007 | FILTER |
| 3003-001237 | MIC6000 | MIC-CONDENSOR |
| 3301-002078 | R6011 | CORE-FERRITE BEAD |
| 3301-002122 | L2005,L2006,L6008 | CORE-FERRITE BEAD |
| 3301-002122 | L6018 | CORE-FERRITE BEAD |
| 3301-002223 | L7000,L7001,L7002 | CORE-FERRITE BEAD |
| 3301-002223 | L7004 | CORE-FERRITE BEAD |

5. MAIN Electrical Parts List

| 3301-002235 | L6001,L6003,L6004 | CORE-FERRITE BEAD |
|-------------|-------------------|---------------------|
| 3301-002235 | L6005,L6006,L6007 | CORE-FERRITE BEAD |
| 3301-002235 | L6009,L6013 | CORE-FERRITE BEAD |
| 3301-002237 | L1000,L2027,L2037 | CORE-FERRITE BEAD |
| 3301-002238 | L2013,L2017,L2019 | CORE-FERRITE BEAD |
| 3301-002238 | L3012,L6000,L6002 | CORE-FERRITE BEAD |
| 3301-002239 | L2011 | CORE-FERRITE BEAD |
| 3301-002242 | L2036 | CORE-FERRITE BEAD |
| 3301-002312 | L2014,L2016,L2018 | CORE-FERRITE BEAD |
| 3301-002312 | L7005,L7008,L7010 | CORE-FERRITE BEAD |
| 3301-002331 | L5008 | CORE-FERRITE BEAD |
| 3705-001937 | RFS1000,RFS1001 | CONNECTOR-COAXIAL |
| 3709-001932 | SIM4UP | CONNECTOR-CARD EDGE |
| 3709-001933 | SIM3 | CONNECTOR-CARD EDGE |
| 3709-001934 | SIM1,SIM2 | CONNECTOR-CARD EDGE |
| 3710-003193 | SOC7000 | CONNECTOR-SOCKET |
| 3710-003985 | SOC6000 | CONNECTOR-SOCKET |
| 3711-007107 | HDC7002 | CONNECTOR-HEADER |
| 3711-007295 | HDC7001 | CONNECTOR-HEADER |
| 3711-008511 | HDC7003 | CONNECTOR-HEADER |
| 3711-008847 | BTC5000 | CONNECTOR-HEADER |
| 3711-008997 | HEA5000 | CONNECTOR-HEADER |
| 3712-001621 | ANT2000,ANT2001 | CONNECTOR |
| 3712-001621 | ANT2002,ANT2003 | CONNECTOR |
| 3712-001621 | ANT2004,ANT2008 | CONNECTOR |
| 3712-001621 | ANT5000,ANT5001 | CONNECTOR |
| 3712-001621 | ANT5003,ANT5004 | CONNECTOR |
| 3712-001621 | ANT5006 | CONNECTOR |
| 3712-001626 | ANT2006,ANT2009 | CONNECTOR |
| 3712-001633 | ANT3001,ANT3004 | CONNECTOR |
| 3712-001633 | ANT5002,ANT5005 | CONNECTOR |
| 3712-001666 | ANT6000,ANT6001 | CONNECTOR |
| 3712-001714 | ANT3000,ANT3002 | CONNECTOR |
| 4709-002196 | F2004 | RF-MODULE |
| 4709-002412 | F1000,F1001 | RF-MODULE |
| GH02-18335A | SC6005SP | EMI SHEET |
| GH61-08634A | CON1000 | C-CLIP |
| GH62-00042A | GA7000 | GASKET |
| GH63-16268A | SC6000 | SHIELDCAN |

5. MAIN Electrical Parts List

| GH63-16890A | SC6002 | SHIELDCAN |
|-------------|--------|-----------|
| GH63-16937A | SC6003 | SHIELDCAN |
| GH63-16938A | SC6004 | SHIELDCAN |
| GH98-44134A | SC6005 | SHIELDCAN |

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.