

#### 7-1. Components on the Rear Case





#### 7-2. Pre-requisite



## 7-3. Parts which must be changed after repair

BOM Description & part code	Image	Remarks
Backglass Tape [GH81-16711A]		Whenever re-assemble Backglass. Remove old tape and use new tape

#### 7-4. Disassembly

- 1
- Put the device in the chamber or Hot plate as below heating condition
- SOC 68%↓: 70 °C/10~20min
- SOC 68%↑: Discharge until 68%↓
- \* Please confirm the heating condition released lastly, and follow it.
- 2 )Detach the Backglass using disassembly jig.
- \*\* Below picture shows how to detach Back Glass using service jig, however you can use manufactural jig if possible.



2 ||

Disassemble SIM Tray from device. Unscrew 13Points.



Caution

Be careful not to damage set and OCTA.

**3** Disassemble the REAR from Front Assy.






Caution

Be care of scratch and molding damage.

4

- 1. Disassemble Connector 3ea from PBA.
- 2. Unscrew 1 Points from PBA.
- 3. Disassemble Coaxial Cable 2ea from PBA.




Caution


Be care of damage to components.

Caution


Be careful not to damage the PBA.

5 Disassemble PBA Assy from Front Assy.
Disassemble Front /Rear Camera from PBA.





6 Detach RCV from Front Ass'y.



Caution

1) Be careful not to damage the PBA.

7

Detach Motor from Front Ass'y.


**\*** Caution

Be careful not to damage the RCV.

8

Remove FPCB 2ea and Fingersensor fix screw 2ea+Fingersensor FPCB and RF Cable 2ea.





Caution

Be careful not to damage the Motor.

Caution

Be careful not to damage the Sub PBA and connector

9

Detach Finger sensor.

10

Detach HB PBA and the Sub PBA.





Caution


Be careful not to damage fingersenosr and the Sub PBA

Caution

Be careful not to damage HB PBA and the Sub PBA

11

Detach SPK from Rear Ass'y.




Caution

Be careful not to damage the SPK

#### 7-5. Assembly

Attach SPK on Rear Ass'y.







#### Caution Be care of SPK damage.

3


Attach RF Cable 2ea and FPCB 2ea, fingersensor Screw 2ea & FPCB.

Screw insertion 2 Point. \* Torque Value : 0.95



**\*** Caution Be care of Sub PBA damage.

4 Attach Motor and Receiver in upper area.




Please keep the guide line for C to C FPCB and BLACK, WHITE COAXIAL CABLE.

- 1) Be care of scratch CAM lens
- 2) Be care of damage each part.

5

Assemble the PBA and C to C FPCB 2ea and Batt Conn and BLUE, WHITE COAXIAL CABLE. and VT Camera,



6

Screw insertion 1 Point. \* Torque Value : 0.95 ±7%



Caution

Check for each connector connection

**\*** Caution Be care of PBA damage.

7

Assemble Rear and screw insertion 13 point \* Torque Value : 1.25 ±10%



8 Assemble cover rear and insert SIM/SD Tray



Caution

Be care of PBA damage.

Caution

Be care of scratch Rear cover.