Samsung SM-A025F/G Schematic Diagram












Schematic




































































Γ¥	INC ADDRESS	SERSOR IC
KED	OK 360110110	N200136
77	OK 360110110	180697


LCD-BACKLIGHT















RECEIVER







Mobile1Tech Team












Signal	Description	
KEY VOL UP N	Volume Up	
PM RESIN N	Volume Down	
KYPD PWR N	PWER ON	
KEY AI	TA IMOATX	

Battery Conector





ΤE

VBAT TEST POINT



USB TEST POINT



KEY ST point






UART TEST point





Force USB boot





Mobile1Tech
























SAR Sensor














Mobile1Tech