
7-1. Components on the Rear Case





7-2. Pre-requisite



7-3. Parts which must be changed after repair

BOM description & part code	Image	Remarks
TAPE BACK GLASS REWORK [GH81-16828A]		Disassembly of each part such as Back Glass & Sub UB <u>.</u>
TAPE SUB UB REWORK [GH81-16827A]		

Disassemble the lower plate center guard on

7. Level 2 Repair

7-4. Disassembly



Put the device in the chamber as following below heating condition

- SOC 68%↓: Upper 70°C/Lower 60°C 5 min
- SOC 68%↑: Upper 60 °C/Lower 60 °C 5 min
- Please confirm the heating condition released lastly, and follow it.

Case1



Case2



***** Caution

2

the AOD.

Be care of scratch.

***** Caution

Be care of scratch.

3


- Fix the device on the AOD.
- Align the left of the camera deco hole & the right RCV hole with absorber the Upper Plate
- Press the OCTA mode button and it disassembled automatically.




Remove the backglass & Sub UB taps (only outside tape)

Lower plate center guard

Backglass tapes & Sub UB Can Not be reused.










Be care of Rear damage.

- ***** Caution
- 1) Be care of scratch.
- 2) Be care of Rear and connector damage.
- 3) Be care of NFC ANT damage.







6 First open the Battery con, remove sim tray and screws, open the all connectors. Take the main PBA out from bracket.



- ***** Caution
- 1) Be care of scratch.
- 2) Be care of damage on the antenna patterns in rear case.

 - 7
 - Disconnect camera from main PBA.



Main Camera Front Camera

- Caution
- 1) Be care of scratch.
- 2) Be care of Rear and connector damage.3) Be care of NFC ANT damage.
- - 8 Remove motor using top-rounded tweezer.



Motor: Gently insert top-round tweezers to the hole for disassembly and lift it up softly.

- Caution
- 1) Be care of scratch.
- 2) Be care of connector damage.

- Caution
- 1) Be care of scratch.
- 2) Be care of Rear and connector damage.
- 3) Be care of NFC ANT damage.

9

Put ethyl alcohol into the out side of battery with clean swab(①)

Lift battery using battery disassembly vacuum. Remove all residues of tape (the battery tapes Can not be re-used)







10

★ Caution of Handling Ethyl Alcohol ★ Do not touch any print area on the Battery pouch.

There are below information:

- Production vendor
- Production date
- Production line
- Serial number
- Lot / Batch Number

Do not touch LDI(Liquid Damage Indicator) on the Sensor FPCB(Entrance of Sim card tray).







[Notice]

- 1. <u>Do NOT use any sharp tools(disassembly stick, knife, any plastic or tweezers).</u>
- 2. Do NOT reuse the battery and battery tapes.
- 3. In case of battery replacement, transfer the IMEI label on the old battery to the new battery.


If the battery is not properly removed, it may lead to damage to the phone and battery.

Only authorized service providers with the instructions provided can remove the battery.

Caution

Be care of sensor FPCB.

7-5. Assembly



5

Top piece

Assemble the rear case, bottom piece first. Assemble the top piece as following sequence.

Top piece

6

Tighten 21 screws on the rear case.

- Torque force : 1.3 kgf·cm² ± 7% (1.20~1.39)
- Screw Specification : 1.4 * 3.5, Silver
- Refer to the screw tightening sequence







***** Caution

Watch out not to give any damage on the antenna patterns during screwing.

Caution
 Watch out

Watch out not to give any damage on the antenna patterns during screwing.

7

Attach the back glass tape & Sub UB tape on the rear case.

- Attach the backglass tape on the rear case by hands.
- Gently press on the adhesive parts of tape using thumb.

8

Assemble the back glass.

- Softly remove the protection film of outside tapes on the rear cases.
- Hold a device with one hand, and put the back glass with another hand from top to bottom
- Press the outside of back glass & Sub UB with thumbs enough.



Bottom



Caution

Be care of scratch.

Caution

Be care of scratch and REAR damage.

9

Check if there is any gap or difference between back glass/Sub UB and metal frame.

Press the back glass & Sub UB using pressing jig and pad.

- Pressing force : 1N (It is set on the pressing jig in advance)

- Pressing time : 1 minute

Take the device out, and do the visual inspection again.





Back glass

Sub UB

Caution

Be care of scratch and REAR damage.