
7-1. Components on the Rear Case



7-2. Pre-requisite



Confidential and proprietary-the contents in this service guide subject to change without prior notice Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

7-3. Parts which must be changed after repair

BOM Description & part code	Image	Remarks
Fingerprint Tape [GH81-16716A]	0	Whenever re-assemble Fingerprint. Remove old tape and use new tape
TAPE REAR DECO [GH81-16847A]		Whenever re-assemble Back Cover. Remove old tape and use new tape

7-4. Disassembly




Confidential and proprietary-the contents in this service guide subject to change without prior notice Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5 Remove 1 PBA screw



Remove the PBA and C to C FPCB and Batt Conn and BLACK, Blue coaxial cable and VT




Caution
Be careful not to damage the PBA

Caution

Be care of several kinds of damage at PBA and FPCB.

7 Remove CAM connectors

8 Detach RCV from Front Ass'y.





Caution
Be careful not to damage the Camera Module

***** Caution

Be careful not to damage the RCV.

9 Detach Motor from Front Ass'y.



Remove C to C FPCB and BLUE Coaxial cable.



***** Caution

11

Be careful not to damage the Motor.

Data da como a della Colo DD

Detach serew and the Sub PBA.



Caution

Be careful not to damage the C to C FPCB and BLACK, WHITE coaxial cable.

12 Detach SPK from Rear Ass'y



***** Caution

Be careful not to damage HB PBA and the Sub PBA.

***** Caution

Be careful not to damage the SPK.

7-5. Assembly

1 Attach SPK on Rear Ass'y.



2 Attach screw and Sub PBA on Front Ass'y.



Caution
Be care of SPK damage.

Caution
Be care of Sub PBA damage.

Attach C to C FPCB and Blue coaxial cable.



4 Attach Motor and Receiver in upper area





Caution

Please keep the guide line for C to C FPCB and BLACK, WHITE coaxial Cable.

- Caution
- 1) Be care of scratch CAM lens
- 2) Be care of damage each part.

Confidential and proprietary-the contents in this service guide subject to change without prior notice Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

Assemble the PBA and C to C FPCB and Batt Conn and BLUE coaxial cable and VT Camera.



6 Screw insertion 1 Point.

* Torque Value : 1.2 ±7%



Caution

Check for each connector connection

Caution
Be care of PBA damage.

Assemble Rear and screw insertion 13 point
* Torque Value : 1.2 ±7%

8

Assemble Finger print module and connect FPCB



Caution
Be care of PBA damage

Caution

Be care of Finger Print FPCB damage.

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

