

# 8. Level 3 Repair (VIETMOBILE.VN)


## 8-1. Block Diagram



# 8-2. PCB Diagrams 8-2-1. Top





#### 8-2-2. Bottom




#### 8-3. LOGIC


#### 8-3-1. Power On







# **TRANSCEIVER**







#### 8-3-2. LCD Working









#### 8-3-3. TSP










#### 8-3-4. Audio Working

#### Speaker Working








# Receiver Working Operate Receiver NG Check Receiver Resolder Contact Contact ANT600,ANT601 ANT600, ANT601 Signal on in NO VR601, VR602 Resolder or Replace C675 ,C678, VR601, VR602, C675, C678, YES YES Receiver break Change Receiver down? NO NO. Resolder or Replace Check **UCP300 UCP300** YES Change main PBA




#### MIC Working










#### ■ Stereo Headset Working












## 8-3-5. KEY Working

#### Power KEY








# **PWRKE**




# Volume Key and Other Sub key










# 83-6. Vibrator Working













## 8-3-7. T-Flash Card Working







### 8-3-8. SIM Card Working







# 8-3-9 CAMERA Working













# **VT CAM**






## 8-3-10 Charging Working







Switching Charger + Cam Flash LED




#### 8-4-1. GSM850 Rx




#### 8-4-2. GSM900 Rx





#### 8-4-3. DCS Rx




#### 8-4-4. PCS Rx














## 8-4-5. WCDMA Band1 (2100) Rx















# 8-4-6. WCDMA Band8 (900) Rx










#### 8-4-7. GSM850/900 Tx










**TRANSCEIVER** 




#### 8-4-9. DCS/PCS Tx










**TRANSCEIVER** 










**TRANSCEIVER** 









**TRANSCEIVER** 





### 8-4-11. FM RADIO







# WIFI / BT / FM









#### 8-4-12.Bluetooth / WiFi




### WIFI/BT/FM





**TRANSCEIVER** 




### 8-4-13. GPS










# U402 (SC2723S)

	1	2	3	4	5	6	7	8	9	10	11	12	13
Α	NC	VDD_SIM2		AVDD_2 V8	OSC32KO		BAT_DET	VDD_2V8		VDD_DCXO		VDD_WVFI PA	NC
В	VDD_SI M O	MB_CCV	VDD_CAMA	VBATTBK	CTK35K^DC XO	OSC32M	ADCI 3	ADOI 2	VID_SDCO RE	VDD_BMM0000 RE	VDD_CAMMOT	VI BR_OUT	KPLED_O UT
С	EXT_RST _B	OH P_SLEE P	PTEST	VPP		DOXO_LON_C UR	ADCI 1	VBATA		VBATPA		VSSPA	PA_QJTN
D		XTL_BUF_E N1	OLKI N <u>.</u> 26M HZ		VBATD	RTC_MODE	EXTRSTN	VBATA		VBATPA	AVDDPA	VSSPA	PA_CUTP
E	OLK32K	ALD_SCLK	XTL_BUF_E N0	ANT_I N T	VBATD	VSS		ALXMI CP				EARP	EARN
F	ALD_ADD 0	ALD_ADSYN C	ALD_DAD1	ALD_DA D0		VSS	МСР	ALXMI ON	HEADM OP	M CEI AS	HEADMI OBI AS	ALXMI CEI AS	
G		ALD_DASYN C	ADI_SYNC	ADI_SC LK		VSS	M CN		HEADMI ON	Al L1	AI R1	VDDAO	AVDDVB
н	ADI_D	PBI NT2		PRODIT	VSS		VBATALD	HEADM C_ I N	GVD_DET	AGND/B	HEAD_P_R	VCCOM	VOM
J	PBI NT	EXT_XTL_E N0	SENSE_N		VSS	VSS	HEADSET_L_I NT		VREFN	AMPG_VCOM	HEAD_AMPG_I NR	HEAD_P_L	
к		VBATSEN	SENSE_P		VOHG	VDD_1\/8	VSS	CPNEG	HEAD_DRO _L	HEAD_DRO_R		HEAD_AMPG_I NL	VIDDAMP
L	VDD_SDI O	ADD_R88					VSS			CPGND	VBATCG	CAP_N	CAP_P
М	LX_MBM	VFB_MEM	BATDET_VR EF		VSSDRV	VSSDRV			VSSDRV	VBATIDRV		VDD_CAMI O	
N		VFB_RF		VBATDR V	VSSDRV	VSSDR/	VSSDRV	VSSDRV	VBATDRV		VDD_ŒN1	VDD_CAMD	LX_ŒN
Р	VFB_ARM	VFB_CORE	LX_CORE	VBATIDR V	VSSDR/	LX_A <b>R</b> M	VBATORV	VBATDRV	VFB_WPA	APC_VIPA	VDCDC_GEN	VDD_RF0	
R	NC	LX_COR€	LX_CORE	VBATOR V	VSSDRV	LX_ARM	LX_ARM	VBATDRV	LX_RF		LX_VPA	VDD_ŒN0	NC

## UCP300 (SC7727S)



#### **UME300**

