Samsung SM-G973F Schematic Diagram





Diagram



Schematic



SM-G973F REV0.7

Mobile1Tech.com

sheet01: RF (1/2)

sheet02: RF (2/2)

sheet03: CP, TRANSCEIVER, MEMORY

sheet04: SENSORS, HUB, BT/WIFI, NFC, GPS, FM, BTP

sheet05: EXYNOS8895, SIM SOCKET

sheet06: EXYNOS8895

sheet07: POWER(PMIC), IF PMIC, WPC, MST

sheet08: AUDIO CODEC, SUB PCB

sheet09: DISPLAY, CAMERA

sheet10: IRIS CAM, DUAL CAM







Diagram __/





Schematic
















LB LFEM (GSMLB, B5/8/12/13/17/18/19/20/26/28)



OMH LFEM1 (GSMHB, B1/2/3/4/7/25/32/66, TDD B38/40/41)



OMH LFEM2 (B40 SCC_B1/3/7/40 4RX, TDD B39)

