

Connection happens on endpoint init, which rings doorbell on iface. Communication between remote endpoint init function and local callback thread

