

Packet Tracer - Configure Router-on-a-Stick Inter-VLAN Routing

Addressing Table

| Device | Interface | IPv4 Address | Subnet Mask | Default Gateway |
|--------|-----------|--------------|---------------|-----------------|
| R1 | G0/0.10 | 172.17.10.1 | 255.255.255.0 | N/A |
| | G0/0.30 | 172.17.30.1 | 255.255.255.0 | N/A |
| PC1 | NIC | 172.17.10.10 | 255.255.255.0 | 172.17.10.1 |
| PC3 | NIC | 172.17.30.10 | 255.255.255.0 | 172.17.30.1 |

Objectives

Part 1: Add VLANs to a Switch

Part 2: Configure Subinterfaces

Part 3: Test Connectivity with Inter-VLAN Routing

Scenario

In this activity, you will configure VLANs and inter-VLAN routing. You will then enable trunk interfaces and verify connectivity between VLANs.

Instructions

Part 1: Add VLANs to a Switch

Step 1: Create VLANs on S1.

Create VLAN 10 and VLAN 30 on S1.

```
S1(config) # vlan 10
S1(config-vlan) # vlan 30
```

Step 2: Assign VLANs to ports.

- a. Configure interfaces F0/6 and F0/11 as access ports and assign VLANs.
 - Assign the port connected to PC1 to VLAN 10.
 - Assign the port connected to PC3 to VLAN 30.

```
S1(config-vlan)# int f0/11
S1(config-if)# switchport mode access
S1(config-if)# switchport access vlan X (use the appropriate vlan number)
S1(config-if)# int fa0/6
S1(config-if)# switchport mode access
S1(config-if)# switchport access vlan X (use the appropriate vlan number)
```

b. Issue the **show vlan brief** command to verify VLAN configuration.

```
S1# show vlan brief
```

| VLAN Name | Status | Ports |
|-------------------------|--------|--|
| 1 default | active | Fa0/1, Fa0/2, Fa0/3, Fa0/4 Fa0/5, Fa0/7, Fa0/8, Fa0/9 Fa0/10, Fa0/12, Fa0/13, Fa0/14 Fa0/15, Fa0/16, Fa0/17, Fa0/18 |
| | | Fa0/19, Fa0/20, Fa0/21, Fa0/22 Fa0/23, Fa0/24, Gig0/1, Gig0/2 |
| 10 VLAN0010 | active | Fa0/11 |
| 30 VLAN0030 | active | Fa0/6 |
| 1002 fddi-default | active | |
| 1003 token-ring-default | active | |
| 1004 fddinet-default | active | |
| 1005 trnet-default | active | |

Step 3: Test connectivity between PC1 and PC3.

From PC1, ping PC3.

Were the pings successful? Why did you get this result?

Part 2: Configure Subinterfaces

Step 1: Configure subinterfaces on R1 using the 802.1Q encapsulation.

- a. Create the subinterface G0/0.10.
 - Set the encapsulation type to 802.1Q and assign VLAN 10 to the subinterface.
 - Refer to the Address Table and assign the correct IP address to the subinterface.

```
R1(config) # int g0/0.10
R1(config-subif) # encapsulation dot1Q 10
R1(config-subif) # ip address 172.17.10.1 255.255.255.0
```

b. Repeat for the G0/0.30 subinterface.

```
R1(config-subif)# int g0/0.30
R1(config-subif)# encapsulation dot1Q XX (use the appropriate number)
R1(config-subif)# ip address A.B.C.D 255.255.255.0(use the appropriate ip address)
```

Step 2: Verify Configuration.

a. Use the **show ip interface brief** command to verify subinterface configuration. Both subinterfaces are down. Subinterfaces are virtual interfaces that are associated with a physical interface. Therefore, in order to enable subinterfaces, you must enable the physical interface that they are associated with.

R1(config)# interface g0/0

R1(config-if)# no shutdown

b. Enable the G0/0 interface. Verify that the subinterfaces are now active.

Part 3: Test Connectivity with Inter-VLAN Routing

Step 1: Ping between PC1 and PC3.

From PC1, ping PC3. The pings should still fail. Explain.

Step 2: Enable trunking.

a. On S1, issue the show vlan command.

What VLAN is G0/1 assigned to?

b. Because the router was configured with multiple subinterfaces assigned to different VLANs, the switch port connecting to the router must be configured as a trunk. Enable trunking on interface G0/1.

```
S1(config-if)# int g0/1
S1(config-if)# switchport mode trunk
```

How can you determine that the interface is a trunk port using the **show vlan** command?

c. Issue the **show interface trunk** command to verify that the interface is configured as a trunk.

Step 3: Test Connectivity

If the configurations are correct, PC1 and PC3 should be able to ping their default gateways and each other.

What addresses do PC1 and PC3 use as their default gateway addresses?

** Remember to save the .pka file and submit to Canvas.