

HD SH 303 Stainless Steel Custom Flow Control Valve for Showers

Installation Instructions

The 303 Stainless Steel Flow Control Valve for Showers with a National Sanitation Foundation (NSF) Certified Washer is easily installed.

View installation video @ www.hdconservation.com/products

- 1. Detach shower hose from the post on the wall.***
- 2. Run water to clear debris from supply line.
- 3. Check the FCV washer to ensure it is fully seated in the FCV.
- 4. Wrap plumbers tape around the thread of the post.
- 5. Attach the Custom Flow Control Valve to the post and tighten.
- 6. Ensure the 303 Stainless Steel Flow Control Valve is installed tightly and securely. Be sure not to over tighten.
- 7. Attach the shower supply line to the Custom Flow Control Valve already attached to the post by screwing it onto the thread of the FCV and tighten.
- 8. Check for leaks. (tighten or add plumbing tape until leak subsides)
- 9. Your Shower is now ready for use.



***Make sure to install the flow control valve between the wall post and the back end of the shower hose.