






H1 MountingHole_Pad
GND
H2 MountingHole_Pad
GND
H3 MountingHole_Pad
GND
H4 MountingHole_Pad
GND


H5 MountingHole
H6 MountingHole
H7 MountingHole
H8 MountingHole
H9 MountingHole
H10 MountingHole
H11 MountingHole
H12 MountingHole
H13 MountingHole
H14 MountingHole
H15 MountingHole
H16 MountingHole
H17 MountingHole
H18 MountingHole
H19 MountingHole
H20 MountingHole
H21 MountingHole
H22 MountingHole
H23 MountingHole
H24 MountingHole
H25 MountingHole
H26 MountingHole
H27 MountingHole
H28 MountingHole
H29 MountingHole
H30 MountingHole
H31 MountingHole
H32 MountingHole
H33 MountingHole
H34 MountingHole
H35 MountingHole
H36 MountingHole
H37 MountingHole
H38 MountingHole
H39 MountingHole
H40 MountingHole

Sheet: /
File: SoundBoxSTM32_cheap.kicad_sch
**Title:**
Size: A4 | Date: | **Rev:**
KiCad E.D.A. 10.0.3 | Id: 1/7


Using GT-TC048D-H025-L1 (same footprint)
KiCAD datafile not found




| | | |
|---|---|---|
| Sheet: /Reset/ | | |
| File: reset.kicad_sch | | |
| **Title:** | | |
| Size: A4 | Date: | **Rev:** |
| KiCad E.D.A. 10.0.3 | | Id: 2/7 |





| | | |
|---|---|---|
| Sheet: /Power/ | | |
| File: power.kicad_sch | | |
| **Title:** | | |
| Size: A4 | Date: | **Rev:** |
| KiCad E.D.A. 10.0.3 | | Id: 3/7 |




Sheet: /Leds/
File: leds.kicad_sch

**Title:**


Size: A4 | Date: | **Rev:**
KiCad E.D.A. 10.0.3 | Id: 4/7





Sheet: /Switches/
File: switches.kicad_sch


**Title:**

Size: A4 | Date: | **Rev:**
KiCad E.D.A. 10.0.3 | Id: 5/7




| | | |
|---|---|---|
| Sheet: /Audio/ | | |
| File: audio.kicad_sch | | |
| **Title:** | | |
| Size: A4 | Date: | **Rev:** |
| KiCad E.D.A. 10.0.3 | | Id: 6/7 |




Sheet: /SMT32/
File: stm32.kicad_sch

**Title:**

Size: A4 | Date: | **Rev:**
KiCad E.D.A. 10.0.3 | Id: 7/7