
18 CONNECTOR INFORMATION


ACC socket (Continued)

♦ OPC-599 ACC conversion cable pin assignments

The OPC-599 ACC conversion cable connects between a 13 pin [ACC] socket and 7 pin and 8 pin sockets.



Microphone connector



Front panel view

PIN No.	DESCRIPTION
1	Microphone input (Impedance: 600 Ω)
2	+8 V DC output (Maximum 10 mA)
3	Up: Ground Down: Ground through 470 Ω
4	Grounded when the squelch opens.
(5)	PTT
6	PTT ground
7	Microphone ground
8	AF output (varies with the [AF] control.)

♦ External keypad

A circuit is used to output memory content from 4 memories. You can output desired memory content such as that from a CW Memory keyer (M1 \sim M4), Voice memory (T1 \sim T4), RTTY Memory (RT1 \sim RT4) to be transmitted.

- Push a switch to send the memory information.
- Hold down the switch for 1 second to repeatedly send the memory information.
- To use the external keypad, turn ON the following items in the CONNECTORS set screen. (p. 12-8)

MENU » SET > Connectors > External Keypad

VOICE: ONKEYER: ONRTTY: ON

The External keypad is not supplied by Icom. (User supplied)

