Operation while playing back (Continued)

### ◇ VOICE PLAYER screen

Start Time
The recording start time of the file being played back.

The number of file
The number of the file being played back, and the total number of recorded files.

Rewind   Forward

Play the previous file   Play the next file

Touch to pause or playback

Recording Information
Operating frequency, operating mode, and audio type: Receive (RX) or Transmit (TX).

Playback process
Displays progress of the file currently playing back.

Playback time
The playback elapsed time.

Playback icon
Displayed while playing back.
ⓘ Not displayed while paused.

Total time
The total time of the recorded file.

Checking the file information

The transceiver can display the recorded file's operating frequency, operating mode, date, and so on.

1. Open the PLAY FILES screen.
   MENU » RECORD > **Play Files**

   • The folder list is displayed.
2. Select a folder that contains the file you want to playback.

   • The file list is displayed.
3. Touch the desired file to check for 1 second.

   • Opens the QUICK MENU screen.
4. Touch "File Information."

5. To close the PLAY FILES screen, push **EXIT** several times.