
8 **USING AN SD CARD**

Backing up the data saved on the SD card onto a PC (Continued)

Making a backup file on your PC


Windows 7 is used for these instructions.

- 1. Insert the SD card into the SD card drive or a memory card reader* on your PC. *User supplied.
- The "AutoPlay" screen is displayed, as shown to the right.
 - Click "Open folder to view files."
- · Displays the IC-7300 folder.
- 3. Right-click "Removal Disk," and then click "Copy."



 Pastes the copied SD card data onto the hard disk. (Example: Pasting into the "Backup" folder in the C drive)

- 5. When removing the SD card from your PC, be sure to safety remove it.
 - The screen shot shows when a memory card reader is inserted.
- 6. After "Safe To Remove Hardware" is displayed, remove the SD card from your PC.



Libraries

■ Videos