Section 12 SET MODE

Set mode description	12-2
♦ Entering the Set mode	
Tone Control	12-3
Function	12-4
Connectors	12-7
Display	12-10
Time Set	12-1
SD Card	12-1
Others	12-1