Section 19 CONTROL COMMAND

Remote control (CI-V) information	19-2
♦ CI-V connection	19-2
♦ Preparing	19-2
♦ Data format	19-2
♦ Command table	19-3
♦ Data content description	19-8