4 RECEIVING AND TRANSMITTING

Operating RTTY (FSK) (Continued)

♦ Turning ON the RTTY log

Turn ON the RTTY log to save your TX and RX RTTY operating record onto an SD card (user supplied).

- 1. Insert an SD card into the IC-7300. (p. 8-2)
- 2. Open the RTTY DECODE LOG screen in the RTTY mode.

MENU » DECODE > <1> > LOG

3. Select "Decode Log."



4. Select "ON."



- 5. Push **EXIT**.
 - "•" is displayed on the RTTY DECODE screen when the RTTY log is ON.



6. To turn OFF the RTTY log, select "OFF" in step 4.

TIP: How to reset to the default setting

Touching the item or its option for 1 second displays the Quick menu, and then touch "Default" to reset to the default setting.

♦ Viewing the RTTY log contents

You can check the RTTY log contents.

- 1. Insert an SD card with the desired log. (p. 8-2)
- 2. Open the RTTY DECODE LOG VIEW screen in the RTTY mode.

MENU » DECODE > <1> > LOG VIEW

Select the desired log file to view.
The file with "•" is logging. You cannot check this log's contents.



RTTY DECODE LOG VIEW screen



Example of a log saved in the text format.

4. To close the RTTY DECODE screen, push **EXIT** several times.