Checking the folder information

The transceiver can display the folder's name, number of the files in the folder, total capacity of the files and date.

- Open the PLAY FILES screen.
 MENU » RECORD > Play Files
 - The folder list is displayed.
- 2. Touch the desired folder you want to check the contents of for 1 second.



- Opens the QUICK MENU screen.
- 3. Touch "Folder Information."





4. To close the PLAY FILES screen, push **EXIT** several times.

Deleting a file

You can delete the recorded audio file.

- Open the PLAY FILES screen.
 MENU » RECORD > Play Files
 - · The folder list is displayed.
- Select a folder that contains the file you want to delete.



- The file list is displayed.
- 3. Touch the desired file to delete for 1 second.



- Opens the QUICK MENU screen.
- 4. Touch "Delete."



- "Delete file?" is displayed.
- 5. Touch [YES].



- The selected file is deleted.
- 6. To close the PLAY FILES screen, push **EXIT** several times.

♦ Deleting all files

If you want to delete all audio files in the folder at one time, select "Delete All" in step 4 above.