

User KEY



Reset circuit



BOOT Settings



RTC circuit





STM32 Power supply





Indicator light



Type-C interface



SW debug download interface



5V -> 3.3V Power conversion

Title		
Size A3	Number	Revision
Date:	Sheet	of
File:	Drawn By:	