

Installation of Eclipse and IOT2000 SDK

- Setup Windows development environment -

Download and all necessary programs and libraries:

- 7-Zip file archiver https://www.7-zip.org/
- 2. JAVA SE Runtime (JRE)

http://www.oracle.com/technetwork/java/javase/downloads/index.html

 Eclipse IDE for C/C++ Developers: https://www.eclipse.org/downloads/eclipse-packages/

4. IOT2000 SDK

https://support.industry.siemens.com/cs/document/109744106/simatic-iot2000-eclipse-plugin?dti=0&lc=en-WW

5. Templates and help programs

https://github.com/dyolcubal/eclipse_templates

You can extract the eclipse program and SDK anywhere. My suggestion:

<Drive>:\SHARED\IOT2K SDK

<Drive>:\SHARED\eclipse (<Drive> = C,D,..)

If you install eclipse once, you must switch the workspace for different projects. To prevent this, you can extract eclipse to project folder and select workspace in project folder and check the checkbox on first eclipse startup:

Use this as the default and do not ask again

Example project folder structure:

<Drive>:\PROJECTS\<PROJECTNAME>/eclipse

<Drive>:\PROJECTS\<PROJECTNAME>/workspace

<PROJECTNAME> is the name of your project, for example s7comm.

Install Programs:

- 1. Install 7-Zip
- 2. Install JAVA SE Runtime
- 3. Open Eclipse zip file and extract folder <eclipse> to target eclipse folder.


D. Yolcubal 1




Installation of Eclipse and IOT2000 SDK

Setup SDK:

 Start 7-Zip as administrator !!! and open IOT2000 SDK zip file. Double click on elements until you see the folder sysroots. Select folder sysroots and click "Extract". Select the SDK target folder and start with "OK".



Confirm File Replace with "Yes to All".



Ignore create hard link errors.

D. Yolcubal 2




Installation of Eclipse and IOT2000 SDK


2. Copy setsdk.bat file to SDK folder.



- 3. Run setsdk.bat batch file with double click on Explorer.
 - The batch file sets the environment variable *IOT2K_SDK* permanent to SDK path and you need run the batch file only once.
 - All build settings depend on IOT2K_SDK environment variable.
- 4. You can check the *IOT2K_SDK* environment variable with enter command "set" on commandline.
- 5. Create workspace folder.
- 6. Start eclipse with double click on eclipse.exe



- 7. Select workspace folder.
- 8. Select checkbox if you prevent eclipse to ask workspace on startup.
 - Use this as the default and do not ask again
- 9. Check for eclipse updates



D. Yolcubal 3