

Unphased

Stereo Phase Shifter

User Guide



The Doomsville Soundscapes "Unphased" Stereo Phase Shifter is a phaser effect which can modulate the phase of a signal using one of three LFO waveforms. This phaser can also create a stereo effect, where the phaser will sweep between the left & right channels.

Controls:

SCALE GUI – The small drop-down list at the top centre of the effect's panel allows you to select the plugin's display size. Options are tiny, small, medium, normal, large & giant.

KICK SWITCH - Turns the Phaser on or off (bypass mode).

LFO – Select between 3 different LFO (Low Frequency Oscillator) waveforms to modulate the phase of the input signal: Triangle, Sine & Sawtooth.

RATE – Controls the LFO frequency. As this knob is rotated clockwise, the phasing effect quickens. Ranges from 0.02 to 20 Hz.

DEPTH – Controls the percentage of the LFO's value, which is used to modulate the cutoff frequency of the 6 first order all pass stages in the phaser. Ranges from 0% to 100%.

INTENSITY – Controls the percentage of the feedback from the 6 first order all pass stages in the phaser. Ranges from 0% to 100%. Values between 75% and 95% will sound best.

v 1.0.2 Page 1 of 2

Options:

STEREO – Turns the stereo effect on or off. When on, the phaser will sweep between the left & right channels.

Should you wish to raise any issues you encountered while using this plugin, or review issues raised by other users, including those which have already been fixed, please visit: https://github.com/DoomyDwyer/ASPiKProjects/issues.