

## **Datafication**

https://github.com/Dr-AlaaKhamis/ISE518/tree/main/5\_Datafication

Lecture 6 – Wednesday September 10, 2025

2025 © Dr. Alaa Khamis

## Outline

- Datafication
- Condition Monitoring Sensors
- Data Types
- Design of Experiment (DOE)
- Data Governance

## Outline

### • Datafication

- Condition Monitoring Sensors
- Data Types
- Design of Experiment (DOE)
- Data Governance

### **Datafication**

- **Data explosion:** Today, around 147–181 zettabytes of data are estimated to exist globally, with projections reaching 181 ZB by 2025.
- Recent generation: While exact definitions vary, many estimates suggest that ~90% of this data was generated in just the past two years.
- **Digitization dominance:** Virtually all modern data is digital—already by 2014, data in digital format accounted for over 99% of all stored information.
- Unstructured and user-generated: Around 90% of global data is unstructured, and about 70% is user-generated (e.g., social media, videos, emails)



IoT sensors generate ~200 million TB every day



Autonomous Vehicles: 4-20 TB per day



Facebook: 350 M images uploaded per day



X community generates more than 12 terabytes of data per day




YouTube: 300 hours of video uploaded every minutes



Walmart: 2.5 Petabytes of customer data hourly

## **Datafication**

• Big Data



Data Type	Example
Visual (images/ videos)	<ul> <li>X-rays</li> <li>Computerized tomography (CT or CAT scan)</li> <li>Positron Emission Tomography (PET scan)</li> <li>Magnetic Resonance Imaging (MRI)</li> </ul>
Speech	audio or voice reports
Numerical	<ul><li>Patient card</li><li>Test results</li></ul>
Text	<ul><li>Medical reports</li><li>Reviews</li></ul>
Multimodal	Electronic Medical Records (EMR)

#### • The 4 V's of Big Data

#### **40 ZETTABYTES**

of data will be created by 2020, an increase of 300 times from 2005



#### **6 BILLION PEOPLE**

have cell phones world population: 7 BILLION







#### 2.5 QUINTILLION BYTES

of data are created each day



Most companies in the U.S. have at least


#### **100 TERABYTES**

of data stored



As of 2011, the global size of data in healthcare was estimated to be

#### 150 EXABYTES



### 30 BILLION PIECES OF CONTENT

are shared on facebook every month



### Variety

DIFFERENT FORMS OF DATA

### 4 BILLION + HOURS OF VIDEO

are watched on You Tube each month



#### **4 MILLION TWEETS**

are sent per day by about 200 million monthly active users



The New York Stock Exchange captures

## 1TB OF TRADE INFORMATION

during each trading session \_



### Velocity

ANALYSIS OF STREAMING DATA Modern cars have close to

#### 100 SENSORS

that monitor items such as fuel level and tire pressure



#### 1 IN 3 BUSINESS LEADERS

don't trust the information they use to make decisions



#### Veracity

UNCERTAINITY OF DATA

#### 27% OF RESPONDENTS

in one survey were unsure of how much of data was inaccurate






## **Datafication**

#### • Big data sizes



Byte of data: one grain of rice



Gigabyte: 3 container lorries



Kilobyte: cup of rice



Terabyte: 2 container ships



Exabyte: covers Germany twice



Megabyte: 8 bags of rice



Petabyte: covers Manhattan




Zettabyte: fills the Pacific ocean

### **Datafication**

• How Much Training Data is Required for Machine Learning?

The amount of data required for machine learning depends on many factors, such as:

- The complexity of the problem, nominally the unknown underlying function that best relates your input variables to the output variable.
- The complexity of the learning algorithm, nominally the algorithm used to inductively learn the unknown underlying mapping function from specific examples.




Source]

Amount of data

## Outline

- Datafication
- Condition Monitoring Sensors
- Data Types
- Design of Experiment (DOE)
- Data Governance







Condition Monitoring Sensor Examples: power meter, non-intrusive CTs, Magnets vibration sensor,

temperature sensors.



CT sensors


Power meter



Vibration Sensor



Temperature Sensor



• Non-intrusive CT (Current Transformer) Sensors: clamp around conductors to measure current safely without cutting wires. They transmit real-time data for energy monitoring, load management, and fault detection, making them ideal for smart grids and building management.



- **Vibration Sensor:** Continuous Vibration Monitoring and Protection of Critical Equipment Monitors and protects 24/7
  - Operates off standard 24V loop power
  - Interfaces with plant monitoring &PI systems
  - Installs quickly and easily
  - Provides critical machine information
  - Avoids costly
  - catastrophic failures




• **Power Meter:** 3 phase power meter with current and voltage transducers are mandatory to monitor the electric panels status (On/Off, normal or overload)




- **Temperature Sensors:** provide continuous, real-time data on equipment heat levels without disrupting operations. By detecting abnormal temperature rises, they help predict failures, prevent downtime, and improve safety, making them essential for motors, bearings, and other critical assets.
  - Thermocouples: durable, wide temperature range, common in heavy industry.
  - **RTDs** (Resistance Temperature Detectors): highly accurate and stable, used where precision is critical.
  - Thermistors: sensitive and fast-responding, suited for narrow-range monitoring.
  - Infrared (IR) sensors: non-contact, useful for moving parts or inaccessible surfaces
  - Wireless IoT sensors: enable remote, real-time monitoring and integration with predictive maintenance systems.

- **IoT Gateway:** Multi-communication channels to collect the data from the different sensors and direct this data to the cloud server to be analyzed. The following technical specifications are required:
  - Wi-Fi, Ethernet, RS 485, 3G/4GConnectivity
  - 12 industrial sensor Analog input (4-20 ma)
  - 8 Relay Output 220V/3A
  - Configurable over LAN and WAN
  - Secure access control
  - Sampling rate: up to 10 seconds sensors data
     publish rate



• Operational Dashboard:




## Outline

- Datafication
- Condition Monitoring Sensors
- Data Types
- Design of Experiment (DOE)
- Data Governance

Data Type	Example Sources
Time-Series	Vibration, temperature, pressure, flow, voltage
Acoustic/Ultrasonic	Leak detection, bearing diagnostics
Thermal/Imaging	IR cameras, visual inspections
Event/State Logs	PLC alarms, operational status
Historical Structured	CMMS data, asset metadata
Analytical/Lab	Oil/lubricant, wear debris analysis
Human/Annotation	Operator notes, RCA, inspection logs


- Time-Series Sensor Data
  - Continuously sampled measurements over time, essential for trend and anomaly detection.
  - Vibration data (accelerometers, velocity, displacement)
  - Temperature readings (thermistors, RTDs)
  - Pressure data
  - Flow rate measurements
  - Electrical current & voltage (e.g., motor current signature analysis)
  - RPM / speed / torque sensors
  - Environmental data (humidity, ambient temperature)





#### • Acoustic & Ultrasonic Data


High-frequency signals, often analyzed in waveform or spectrogram formats.

- Ultrasound sensor data (bearing inspection, leak detection)
- Acoustic emissions (early-stage fault detection in mechanical parts)
- Sound recordings (used with ML for diagnostics)











#### • Thermal/Imaging Data


Spatial or pixel-based data capturing thermal signatures or visual cues.

- Infrared thermography (IR images/videos)
- Visual inspections (RGB cameras)
- Thermal maps of components or systems










### • Logo/Event/State Data


Discrete logs or flags representing system state changes or events.

- PLC/DCS alarms and event logs
- Fault codes and error messages
- Start/stop events
- Operating mode/status (idle, running, error)

```
Top problem item: 'أكثر مشكلة تكرازًا: 'ضبط دائرة السيفتي للكيسه وضبط وتثبيت السويتشات ' بعدد 2. أكثر مشكلة تكرازًا: 'ضبط دائرة السيفتي للكيسه وضبط وتثبيت السويتشات ' بعدد 2. Highest total cost spare part: 'Seal Pump 2.5" - BME119A-A00 (20503157)' with 70,952.33. بقيمة 'Seal Pump 2.5" - BME119A-A00 (20503157)' 70,952.33 بقيم الغيار . Job completion rate: 100.0%.

100.0 :انسبة إكمال الأعمال: Shift with highest average NetTime: 3 (95.0 minutes). الوردية ذات أعلى متوسط زمن صافي: 3 (95.0 دقيقة)
```






#### • Structured Historical/Maintenance Data

Tabular data, useful for failure modeling and supervised ML.

- CMMS / EAM data (work orders, failure reports, mean time between failures)
- Asset metadata (make, model, age, location, specs)
- Maintenance logs (corrective, preventive actions taken)
- Downtime records




		timestamp	machine_id	failure_type	anomaly_flag	downtime_risk	maintenance_required	machine_status	machine_status_label
	2	2025-01-01 00:02:00	15	Normal	1	1.0	1	1	running
	3	2025-01-01 00:03:00	43	Normal	1	1.0	1	1	running
	4	2025-01-01 00:04:00	8	Vibration Issue	0	0.0	1	2	error
	8	2025-01-01 00:08:00	23	Normal	1	1.0	1	1	running
	13	2025-01-01 00:13:00	40	Overheating	0	0.0	1	2	error
	15	2025-01-01 00:15:00	3	Normal	1	1.0	1	1	running
	17	2025-01-01 00:17:00	2	Normal	1	1.0	1	1	running
	18	2025-01-01 00:18:00	24	Normal	1	1.0	1	1	running
	21	2025-01-01 00:21:00	38	Normal	1	1.0	1	1	running
	23	2025-01-01 00:23:00	21	Vibration Issue	0	0.0	1	2	error
	26	2025-01-01 00:26:00	22	Normal	0	0.0	1	1	running
	27	2025-01-01 00:27:00	44	Normal	0	0.0	1	1	running

structured format.

 Analytical/Lab Data
 Intermittently collected and labanalyzed, often stored in


- Oil/lubricant analysis (particle count, water content, viscosity)
- Wear debris analysis
- Coolant contamination analysis



Filter Information: Identifies the filter used and its micron rating. **Miscellaneous Information:** Details additional miscellaneous information.

**Product Information:** Identifies the sample lubricant and its properties.


- Human Input / Expert Annotations
  - Qualitative or semi-structured data, increasingly used in supervised learning.
  - Operator observations
  - Manual inspection notes
  - Failure root cause analysis (RCA) reports
  - Expert labeling of fault types



## Outline

- Datafication
- Condition Monitoring Sensors
- Data Types
- Design of Experiment (DOE)
- Data Governance

#### • The 7-Step Procedure



Actionable insights

7. Model Deployment

More info: Alaa Khamis, "The 7-Step Procedure of Machine Learning", towards data science, 2019.

#### 2025 KFUPM © Alaa Kham

#### Controlled Factors

Independent variables that represent design parameters changeable during data collection process

#### Signals

Independent variables or stimuli required for fulfilling the model functionality

#### **RUL Prediction Model**

## Response

Dependent variables that represent primary intended functional output of the model

#### Noise Factors

Independent variables that influence prediction model, controllable during data collection process and uncontrollable after deploying the model

#### Error States

Failure modes or effects of failure as defined by enduser when using the model



CO: Safe Driving



C1: Text Right



C2: Phone Right



C3: Text Left



C4: Phone Left



C5: Adjusting Radio



C6: Drinking




C7: Reaching Behind



C8: Hair or Makeup



C9: Talking to Passenger



#### Controlled Factors

- Motor Type
- · Supply voltage
- Ambient temperature
- · Ambient humidity
- · Sensor type and placement
- · Sampling frequency

#### Signals

- · Motor vibration signals
- · Temperature readings
- · Current and voltage measurements
- Rotational speed (RPM)
- · Acoustic signals

#### **RUL Prediction Model**

#### failure

- Probability distribution of time-to-
- · Confidence interval of RUL estimate

Response

Predicted Remaining Useful Life (RUL)

#### Noise Factors


- Random load fluctuations from production process
- · unexpected voltage dips/spikes
- operator handling differences
- environmental dust/contaminants

#### Error States


- Prediction error (e.g., RMSE or MAE)
- · Biased RUL estimates

in hours or cycles

· False alarms and false negatives



• How do I set up an experiment?



Pros & Cons	Full Factorial	Fractional Factorial
Pros	<ul> <li>All possible combinations can be covered</li> <li>Analysis is straightforward, as there is no aliasing</li> </ul>	<ul> <li>Less memory and effort</li> <li>Less time</li> <li>Runs can be added to eliminate cofounding.</li> </ul>
Cons	Cost of the experiment increases as the number of factors increases	<ul> <li>Analysis of higher order interactions could be complex</li> <li>Cofounding could mask factor and interaction effects</li> </ul>

### Full Factorial Design

$$N_{full} = r \prod_{i=1}^{k} L_i$$

 $N_{full}$  is the number of runs

 $L_i$  is number of levels for factor i

r is number of replicates (optional)

#### Special cases

Two-level factors only  $\Rightarrow N = r 2^k$ 

Three-level factors only  $\Rightarrow N = r 3^k$ 

Controlled Factors Motor Type Supply voltage Ambient temperature Ambient humidity Sensor type and placement Sampling frequency **RUL Prediction Model** Signals Response · Motor vibration signals Predicted Remaining Useful Life (RUL) · Temperature readings in hours or cycles Current and voltage measurements Probability distribution of time-to- Rotational speed (RPM) Acoustic signals Confidence interval of RUL estimate Noise Factors Error States Random load fluctuations from production · Prediction error (e.g., RMSE or MAE) · Biased RUL estimates unexpected voltage dips/spikes · False alarms and false negatives operator handling differences environmental dust/contaminants

**Example:** considering only 3 two-levels controlled factors and 3 two-level noise factors with no replicate:  $N = r 2^k = 2^6 = 64$  runs. If each run takes 30 minutes, the total duration to collect the data would be 1920 minutes (32 work hours or four 8-hour full days).

• Fractional-factorial (regular resolution) for a two-level fractional design

$$N_{frac} = r2^{k-p}$$

k is the total number of factors

p is number of generators (fractionality)

 $p=0 \Rightarrow$  full,  $p=1 \Rightarrow$  half fraction,  $p=2 \Rightarrow$  quarter fraction, etc.

**Example:** considering only 3 two-levels controlled factors and 3 two-level noise factors with no replicate. Number of runs for quarter fraction experiment:  $N = r 2^{k-p} = 2^{6-2} = 16$  runs. If each run takes 30 minutes, the total duration to collect the data would be 480 minutes (8 hours or one full day).


• Fractional-factorial (regular resolution) for a three-level fractional design

$$N_{frac} = r3^{k-p}$$

## Outline

- Datafication
- Condition Monitoring Sensors
- Data Types
- Design of Experiment (DOE)
- Data Governance

### • Data Privacy, Ownership and Equity



- What types of data are collected and shared?
- Why should the data be collected and shared?
- What are the benefits of sharing the data?
- How owns the data?
- With whom the data will be shared?
- When will the data be collected and used?
- How will the data be collected and used?
- Will anonymization and privacy masking be applied on the data?
- What will happen to the user's data or profile when the user dies?